

MAGAZINE DISCONNECT REPLACEMENT FOR SW22 VICTORY - TANDEMKROSS MAGAZINE DISCONNECT REPLACEMENT FOR SW22 VICTORY

[Handgun Parts](#) > [Trigger Group Parts](#) > [Hammer Parts](#) > [Hammer Bushings](#)

Replaces Magazine Safety, Retains Strong Mag Ejection

The new Tandemkross Magazine Disconnect Replacement for the Smith & Wesson SW22® Victory™ is a simple, drop-in replacement for the factory magazine disconnect bar. With the Tandemkross Magazine Disconnect Replacement installed, it permits the removal of the magazine safety while maintaining a strong magazine ejection. Allows for safe removal of magazine safety. Maintains strong magazine ejection. Machined from durable stainless steel. The Tandemkross Magazine Disconnect Replacement simply drops into the SW22 Victory's frame, replacing the magazine safety, allowing the firearm to fire even without a magazine.



Attributes

- Name: [TANDEMKROSS MAGAZINE DISCONNECT REPLACEMENT FOR SW22 VICTORY](#)
- Manufacturer: [TANDEMKROSS](#)
- Product no.: 100023853
- Mfr. No.:
- Model: SW22
- Weapon type: Smith & Wesson
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 76mm
- Shipping length: 108mm
- UPC: 769498482995

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- Startpage
- Safety Instruction Guide for Tandemkross Magazine Disconnect Replacement for SW22 Victory
- About Us

Safety Instruction Guide for Tandemkross Magazine Disconnect Replacement for SW22 Victory

Introduction

Thank you for choosing the Tandemkross Magazine Disconnect Replacement for the Smith & Wesson SW22® Victory™. This product is designed to enhance your firearm's functionality while ensuring safety during use. Please read this safety instruction guide thoroughly to understand how to use and install the product safely and effectively.

General Safety Guidelines

- Always treat firearms as if they are loaded.
- Keep the firearm pointed in a safe direction at all times.
- Ensure that the firearm is unloaded before installation or maintenance.
- Store firearms and ammunition in a secure location, out of reach of children and unauthorized users.
- Be aware of your surroundings and ensure that no one is in the line of fire when handling the firearm.
- Regularly check for any product recalls or safety updates on the EU's Safety Gate platform.
- Report any unsafe product incidents to the appropriate authorities.

Specific Safety Precautions for Use

- The Tandemkross Magazine Disconnect Replacement is intended for use with the Smith & Wesson SW22® Victory™ only.
- Do not attempt to use this product with any other firearm model.
- Ensure that the replacement is installed correctly to avoid accidental discharges.
- Be cautious when handling the firearm after installation, as it can fire without a magazine.
- Always follow safe handling practices when firing the weapon.
- Keep all parts of the firearm clean and well-maintained to ensure optimal performance.

Instructions for Installation and Usage

Installation Steps

1. Preparation

- Ensure the firearm is unloaded.
- Gather necessary tools (if required).

2. Removing the Factory Magazine Disconnect

- Disassemble the SW22 Victory™ according to the manufacturer's instructions.
- Locate the factory magazine disconnect bar and carefully remove it.

3. Installing the Tandemkross Magazine Disconnect Replacement

- Take the Tandemkross Magazine Disconnect Replacement and align it with the frame of the SW22 Victory™.
- Gently drop the replacement into place, ensuring it fits securely.

4. Reassembling the Firearm

- Reassemble the SW22 Victory™ following the manufacturer's instructions.
- Doublecheck that all components are correctly installed and secure.

5. Testing the Installation

- With the firearm pointed in a safe direction, perform a function check to ensure proper operation.
- Confirm that the firearm can operate without a magazine inserted.

Usage Guidelines

- Always follow the manufacturer's guidelines for the SW22 Victory™ when using your firearm.
- Use only compatible magazines with the SW22 Victory™ to ensure safe operation.
- Regularly inspect the Tandemkross Magazine Disconnect Replacement for wear or damage.

Disposal Instructions

- Dispose of the Tandemkross Magazine Disconnect Replacement responsibly.
- Follow local regulations for the disposal of firearm components.
- Do not discard in regular household waste.

Contact Information for Further Support

For any inquiries or support regarding the Tandemkross Magazine Disconnect Replacement for SW22 Victory™, please refer to the manufacturer's website or contact their customer service for assistance.

By following these safety instructions, you can ensure the safe and effective use of your Tandemkross Magazine Disconnect Replacement for the Smith & Wesson SW22® Victory™. Thank you for prioritizing safety and responsibility in firearm usage.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk