

FIRING PIN SPACER FOR GLOCK® GEN 3 - SHADOW SYSTEMS

FIRING PIN SPACER FOR GLOCK GEN 3

[Handgun Parts](#) > [Action Parts](#) > [Firing Pin Parts](#) > [Firing Pin Hardware](#)

The Shadow Gunworks firing pin spacer provides the ideal update for a worn out Glock 19 Gen 3 spacer. Made of Nylon 6 Polymer Fits all Glock Gen 3 models



Attributes

- Name: [SHADOW SYSTEMS FIRING PIN SPACER FOR GLOCK GEN 3](#)
- Manufacturer: [SHADOW SYSTEMS](#)
- Product no.: 100024239
- Mfr. No.: SG9C-00-06
- Weapon type: Glock
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 25mm
- UPC: 853687007073

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Firing Pin Spacer for Glock® Gen 3 Safety Instructions](#)
- [About Us](#)

Firing Pin Spacer for Glock® Gen 3 Safety Instructions

Introduction

Thank you for choosing the Shadow Gunworks Firing Pin Spacer for Glock® Gen 3. This product is designed to enhance the performance of your Glock 19 Gen 3 by replacing worn out spacers. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that this product is compatible with your specific Glock Gen 3 model before installation.
- Always handle firearms and firearm accessories with care, following all safety protocols.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the firing pin spacer for wear or damage before use.
- If you experience any malfunctions or safety concerns, discontinue use immediately and consult a qualified gunsmith.

Specific Safety Precautions for Use

- Only use the firing pin spacer with Glock Gen 3 models.
- Avoid exposing the product to extreme temperatures or harsh chemicals, as these may affect its integrity.
- Do not modify or alter the firing pin spacer in any way.
- Ensure that your firearm is unloaded before installation of the spacer.
- Wear appropriate safety gear, such as eye protection, when handling firearms.

Instructions for Installation and Usage

1. Preparation:

- Ensure your Glock Gen 3 is completely unloaded.
- Gather necessary tools for installation, if required.

2. Installation:

- Remove the slide from the frame of your Glock Gen 3.
- Locate the firing pin assembly within the slide.
- Carefully remove the old firing pin spacer from the assembly.
- Insert the new Shadow Gunworks firing pin spacer into the assembly, ensuring it fits securely.
- Reassemble the slide onto the frame of your Glock Gen 3.

3. Usage:

- After installation, function test the firearm in a safe environment to ensure proper operation.
- Regularly check the firing pin spacer for any signs of wear or damage, especially after extensive use.

Disposal Instructions

- Dispose of the old firing pin spacer and any packaging materials in accordance with local regulations.
- Do not dispose of the product in regular household waste. Check for local recycling programs or hazardous waste disposal options.

Contact Information for Further Support

For any safety inquiries, concerns, or to report unsafe conditions, please contact the manufacturer or a qualified professional. Always ensure you have the latest safety updates regarding your product.

Thank you for prioritizing safety and compliance with the EU General Product Safety Regulation. Your responsible use of the Firing Pin Spacer for Glock® Gen 3 contributes to a safer environment for all.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk