

TRIGGER SPRING FOR GLOCK® GEN 3 - SHADOW SYSTEMS

TRIGGER SPRING FOR GLOCK GEN3

[Handgun Parts](#) > [Trigger Group Parts](#) > [Trigger Parts](#) > [Trigger Springs](#)

Trigger Spring replacement for your Gen 3 Glock fire controls by Shadow Gunworks. Made of 302 Stainless Steel Fits all Glock Gen 3 models except 42, 43



Attributes

- Name: [SHADOW SYSTEMS TRIGGER SPRING FOR GLOCK GEN3](#)
- Manufacturer: [SHADOW SYSTEMS](#)
- Product no.: 100024253
- Mfr. No.: SG9C-00-23
- Weapon type: Glock
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 25mm
- UPC: 853687007240

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TRIGGER SPRING FOR GLOCK® GEN 3
- About Us

Safety Instruction Guide for TRIGGER SPRING FOR GLOCK® GEN 3

Introduction

Thank you for choosing the Trigger Spring for Glock® Gen 3 by Shadow Gunworks. This product is designed to enhance the performance of your Glock firearm. To ensure safe usage and compliance with EU regulations, please read this safety instruction guide carefully.

General Safety Guidelines

- Ensure that the Trigger Spring is compatible with your specific model of Glock Gen 3.
- Always handle firearms with caution and follow all local laws and regulations regarding firearm safety.
- Store the Trigger Spring in a secure location, out of reach of children and unauthorized users.
- Regularly inspect the Trigger Spring for any signs of wear or damage before installation and use.

Specific Safety Precautions for Use

- Only use the Trigger Spring with Glock Gen 3 models, excluding models 42 and 43.
- Do not modify or alter the Trigger Spring in any way.
- Always wear appropriate safety gear, such as eye protection, when handling firearms.
- If you experience any issues with the Trigger Spring, do not use the firearm until the issue is resolved by a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather all necessary tools for installation, including a punch tool and a hammer.

2. Installation Steps:

- Remove the slide from the Glock firearm according to the manufacturer's instructions.
- Locate the existing trigger spring and carefully remove it using the punch tool.
- Take the new Trigger Spring and align it with the trigger mechanism.
- Gently tap the new spring into place using the hammer and punch tool, ensuring it is securely seated.

3. PostInstallation Check:

- Reassemble the firearm and conduct a function check to ensure proper operation.
- If the trigger does not function correctly, disassemble and check the installation again.

4. Usage:

- Always follow safe handling practices when using your firearm.
- Regularly check the Trigger Spring for any signs of wear or malfunction.

Disposal Instructions

- Dispose of the Trigger Spring in accordance with your local regulations for metal recycling.
- Do not dispose of the Trigger Spring in regular household waste.

Contact Information for Further Support

For any safety inquiries or assistance regarding the Trigger Spring for Glock® Gen 3, please contact the manufacturer or your local firearms dealer.

By following these guidelines, you can ensure the safe and effective use of your Trigger Spring for Glock® Gen 3. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk