

# AR-15 SENTRY ADJUSTABLE GAS BLOCKS STEEL SET SCREW - SLR RIFLEWORKS SENTRY GAS BLOCK .875 ADJUSTABLE STEEL SET SCREW

[Rifle Parts](#) > [Gas System Parts](#) > [Gas Blocks](#)

## Lock Down Your Adjustable Gas Block

The SLR Rifleworks Sentry Adjustable Set-Screw Gas Block ensures that AR-15 shooters have the ability to fine-tune their gas system for optimum operation. The SLR Rifleworks Sentry Adjustable Set-Screw Gas Block is constructed with a simple metering system that doesn't use springs or balls and is adjustable through the use of an included tool. Machined from 4140 steel Features QPQ Melonite finish Comes in .625, .750, .875 and .936 diameter sizes The SLR Rifleworks Sentry Adjustable Set-Screw Gas Block is equipped with two set screws that lock the block into the barrel for an ideal gas seal.



## Attributes

- Name: [SLR RIFLEWORKS SENTRY GAS BLOCK .875 ADJUSTABLE STEEL SET SCREW](#)
- Manufacturer: [SLR RIFLEWORKS](#)
- Product no.: 100025369
- Mfr. No.: SA8SM
- Inside Diameter: .875
- Material: Steel
- Style: Adjustable
- Weapon type: AR-15
- Delivery weight: 0.057kg
- Shipping height: 25mm
- Shipping width: 76mm
- Shipping length: 140mm

## Item details

Made in USA

US export classification: 0A501.x

# Table of Contents

- Startpage
- Safety Instruction Guide for the SLR Rifleworks Sentry Adjustable Gas Block
- About Us

# Safety Instruction Guide for the SLR Rifleworks Sentry Adjustable Gas Block

## Introduction

Thank you for choosing the SLR Rifleworks Sentry Adjustable Gas Block. This product is designed to enhance the performance of your AR15 by allowing for finetuning of the gas system. This guide provides essential safety instructions to ensure the safe use and installation of the gas block in compliance with the EU General Product Safety Regulation (GPSR).

## General Safety Guidelines

- Ensure that the gas block is installed by a qualified gunsmith or experienced individual familiar with firearms.
- Always handle firearms with care and follow all safety protocols.
- Keep the gas block and all related components out of reach of children and unauthorized users.
- Inspect the gas block for any signs of damage or wear before installation.
- Do not modify the gas block in any way that may compromise its safety or functionality.
- Follow all local laws and regulations regarding firearms and their components.

## Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye protection, when handling firearms.
- Ensure that the firearm is unloaded before beginning any work on it.
- Use the included tool for adjustments only; do not use makeshift tools that may cause damage.
- Do not exceed the manufacturer's recommended settings for gas flow.
- Regularly check the gas block for secure installation and proper function during routine firearm maintenance.
- Be aware of the potential for gas leakage if the gas block is not properly installed.

## Instructions for Installation and Usage

### Installation Instructions

#### 1. Prepare the Firearm

- Ensure the firearm is unloaded and pointed in a safe direction.
- Remove the existing gas block if applicable.

#### 2. Install the SLR Rifleworks Sentry Adjustable Gas Block

- Align the gas block with the barrel.
- Insert the two set screws provided with the gas block into the designated holes.
- Use the included tool to tighten the set screws securely, ensuring a proper gas seal.

#### 3. Adjust the Gas Flow

- Use the included tool to adjust the gas flow to the desired setting.
- Start with a conservative setting and make incremental adjustments as needed.

#### 4. Reassemble the Firearm

- Reattach any components removed during installation.
- Ensure that all parts are secure and functioning correctly.

## 5. Test the Firearm

- Conduct a function test in a safe environment to ensure the gas block operates as intended.
- Monitor for any unusual sounds or gas leakage during operation.

## Usage Instructions

- Regularly check the gas block for proper function and secure installation.
- Make adjustments only when necessary, following the guidelines provided in this manual.
- Always maintain the firearm according to the manufacturer's recommendations.

## Disposal Instructions

- Dispose of the gas block in accordance with local regulations regarding metal and firearm components.
- If the gas block is damaged beyond repair, ensure it is rendered unusable before disposal to prevent misuse.

## Contact Information for Further Support

For safety inquiries or additional support regarding the SLR Rifleworks Sentry Adjustable Gas Block, please refer to the manufacturer's contact information provided with the product packaging or on the manufacturer's website.

By following these guidelines, you can ensure the safe and effective use of the SLR Rifleworks Sentry Adjustable Gas Block. Always prioritize safety and compliance with local laws and regulations. Thank you for your attention to these important safety instructions.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)