

AR-15 AIRBORNE CHARGING HANDLE - GEISSELE AUTOMATICS AIRBORNE CHARGING HANDLE BLACK

[Rifle Parts](#) > [Bolt Parts](#) > [Charging Handle Parts](#) > [Charging Handles](#)

Won't Interfere With Optic or Other Gear - Still Easy To Operate

Geissele developed its Airborne Charging Handle (ACH) with a low-profile lever that's less likely to get snagged on vegetation and other gear. Geissele designed the ACH at the specific request of an "elite" unit of the United States armed forces so it won't interfere with a red dot sight or similar low-mounted optic. The ambidextrous Airborne Charging Handle's low profile doesn't mean you have to compromise accessibility or ease of use. The ACH's shortened levers have gently concaved radius cuts in both the vertical and horizontal planes so the hand can get a secure purchase. Geissele even gave the ACH lever checkered surfaces to ensure a positive gripping surface, even when your hands are wet or you're wearing gloves. Reliable ambidextrous operation Extra-strong machined 7075 T6 aluminum Type III hardcoat anodized Available in basic Black or Geissele's Desert Dirt Color (DDC) As an added benefit, the Geissele Airborne Charging Handle comes with a raised lip at the aft end that redirects gas blow back away from the shooter when using short-barreled or suppressed weapon systems.



Attributes

- Name: [GEISSELE AUTOMATICS AIRBORNE CHARGING HANDLE BLACK](#)
- Manufacturer: [GEISSELE AUTOMATICS](#)
- Product no.: 100025736
- Mfr. No.: 05-497B
- Finish: Black
- Hand: Ambidextrous
- Weapon type: AR-15
- Delivery weight: 0.068kg
- Shipping height: 19mm
- Shipping width: 102mm
- Shipping length: 235mm
- UPC: 817953022221

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for AR15 Airborne Charging Handle
- About Us

Safety Instruction Guide for AR15 Airborne Charging Handle

Introduction

Thank you for choosing the Geissele Automatics Airborne Charging Handle (ACH). This guide provides essential safety instructions and guidelines to ensure the safe use and handling of your product. Please read this document carefully before installation and use.

General Safety Guidelines

- Always treat all firearms and firearm accessories as if they are loaded.
- Ensure that the firearm is pointed in a safe direction at all times.
- Keep your fingers off the trigger until you are ready to shoot.
- Be aware of your surroundings and ensure that there is a proper backstop before firing.
- Store the charging handle and firearm in a secure location away from children and unauthorized users.
- Regularly inspect the charging handle and firearm for any signs of wear or damage before use.
- Follow all local laws and regulations regarding the use and ownership of firearms and accessories.

Specific Safety Precautions for Use

- Ensure that the charging handle is compatible with your AR15 model before installation.
- Only use the charging handle with firearms that are in good working condition.
- Avoid using excessive force when operating the charging handle to prevent damage.
- Do not attempt to modify or alter the charging handle in any way.
- If you experience any malfunctions or issues, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Remove the existing charging handle from the upper receiver by pulling the rear takedown pin and separating the upper and lower receivers.
- Slide the Geissele Airborne Charging Handle into the receiver's charging handle slot.
- Reassemble the upper and lower receivers by reinserting the takedown pin.
- Ensure the charging handle moves freely and does not obstruct any other components.

2. Usage:

- Grip the charging handle firmly with either hand.
- Pull the charging handle straight back to cycle the action.
- Release the charging handle to allow it to return to its forward position.
- Practice using the charging handle with both hands to become familiar with its operation.

Disposal Instructions

- Dispose of the charging handle in accordance with local regulations for metal recycling or hazardous waste.
- Ensure that the charging handle is not usable before disposal to prevent accidental use.

Contact Information for Further Support

For any questions or concerns regarding the Geissele Airborne Charging Handle, please refer to the manufacturer's website or contact their customer support team for assistance.

By following these guidelines and instructions, you can ensure the safe and effective use of your Geissele Automatics Airborne Charging Handle. Thank you for prioritizing safety in your firearm practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk