

# AR-15 A1 BUTTSTOCK SCREW - LUTH-AR AR-15 A1 BUTTSTOCK SCREW

[Rifle Parts](#) > [Stock Parts](#) > [Butt Plate Parts](#) > [Butt Plate Components](#)

Luth-AR factory replacement A1 Buttstock Screw. Fits standard AR-15 rifles.



## Attributes

- Name: [LUTH-AR AR-15 A1 BUTTSTOCK SCREW](#)
- Manufacturer: [LUTH-AR](#)
- Product no.: 100028029
- Mfr. No.: A101
- Finish: Black
- Material: Steel
- Weapon type: AR-15
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 25mm
- UPC: 859819007300

## Item details

Made in USA

# Table of Contents

- Startpage
- Safety Instruction Guide for AR15 A1 Buttstock Screw
- About Us

# Safety Instruction Guide for AR15 A1 Buttstock Screw

## Introduction

Thank you for choosing the LuthAR AR15 A1 Buttstock Screw. This guide provides important safety information, installation instructions, and guidelines for proper use to ensure your safety and the performance of your firearm.

## General Safety Guidelines

- Always follow firearm safety rules when handling and using your AR15 rifle.
- Ensure that the product is compatible with your specific AR15 model before installation.
- Inspect the screw for any signs of damage or wear before use.
- Store the screw in a safe place, away from children and unauthorized users.
- Report any unsafe products or incidents to the appropriate authorities.

## Specific Safety Precautions for Use

- Use only the LuthAR A1 Buttstock Screw with standard AR15 rifles.
- Do not modify the screw or use it in any way that is not intended by the manufacturer.
- Ensure that the screw is securely fastened before using your firearm.
- Regularly check the screw for tightness and integrity during routine firearm maintenance.
- If you experience any issues with the screw, discontinue use immediately and seek professional assistance.

## Instructions for Installation and Usage

### 1. Preparation

- Ensure the AR15 rifle is unloaded and the chamber is clear.
- Gather necessary tools, including a screwdriver suitable for the screw head.

### 2. Installation

- Locate the buttstock on your AR15 rifle.
- Remove the existing buttstock screw if applicable.
- Align the LuthAR A1 Buttstock Screw with the hole in the buttstock.
- Insert the screw and tighten it securely with the screwdriver, ensuring it is not overtightened.

### 3. PostInstallation Check

- After installation, visually inspect the screw to ensure it is properly seated.
- Perform a function check of the rifle to ensure everything operates correctly.

### 4. Usage

- Always handle your AR15 rifle with care, treating it as if it is loaded.
- Follow all local laws and regulations regarding firearm use.

## Disposal Instructions

- Dispose of the LuthAR A1 Buttstock Screw in accordance with local regulations.

- If the screw is damaged or no longer needed, consider recycling it if possible, or dispose of it in a safe manner to prevent environmental harm.

## Contact Information for Further Support

For any inquiries or concerns regarding the LuthAR A1 Buttstock Screw, please refer to the manufacturer's website or customer service for assistance. Always ensure that you are following the latest safety guidelines and recommendations.

By adhering to these safety instructions and guidelines, you can ensure a safe and effective use of the LuthAR AR15 A1 Buttstock Screw. Thank you for your attention to safety.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)