

AR-15 A2 UPPER BUTTSTOCK SCREW - LUTH-AR AR-15 A2 UPPER BUTTSTOCK SCREW

[Rifle Parts](#) > [Stock Parts](#) > [Butt Plate Parts](#) > [Butt Plate Components](#)

Luth-AR factory replacement A2 Upper Buttstock Screw. Fits standard AR-15 rifles.



Attributes

- Name: [LUTH-AR AR-15 A2 UPPER BUTTSTOCK SCREW](#)
- Manufacturer: [LUTH-AR](#)
- Product no.: 100028030
- Mfr. No.: A2-01
- Finish: Black
- Material: Steel
- Weapon type: AR-15
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 25mm
- UPC: 859819007317

Item details

Made in USA

Table of Contents

- Startpage
- AR15 A2 Upper Buttstock Screw Safety Instruction Guide
- About Us

AR15 A2 Upper Buttstock Screw Safety Instruction Guide

Introduction

Thank you for choosing the LuthAR AR15 A2 Upper Buttstock Screw. This guide provides essential safety instructions to ensure the proper use and installation of the product. Please read this document carefully to understand how to use the product safely and effectively.

General Safety Guidelines

- Always ensure that the firearm is unloaded before performing any maintenance or installation work.
- Use only the LuthAR AR15 A2 Upper Buttstock Screw with compatible AR15 rifles.
- Store this product out of reach of children and unauthorized users.
- Regularly inspect the screw for wear and tear. Replace it if any damage is observed.
- Follow all local laws and regulations regarding firearm modifications and maintenance.

Specific Safety Precautions for Use

- Ensure that the screw is installed correctly to prevent any accidental dislodgment during use.
- Do not use excessive force when tightening the screw, as this may strip the threads or damage the firearm.
- Be aware of any sharp edges on the screw during installation to avoid injury.
- If you are unsure about the installation process, seek assistance from a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation

- Gather the necessary tools: a screwdriver compatible with the screw head and a torque wrench (if applicable).
- Ensure your workspace is clean and free from distractions.

2. Installation Steps

- Check that the firearm is unloaded and the safety is engaged.
- Remove the existing buttstock screw from the AR15 rifle using the screwdriver.
- Align the LuthAR A2 Upper Buttstock Screw with the mounting hole.
- Insert the screw and handtighten it to ensure proper alignment.
- Use the screwdriver to tighten the screw securely, but do not overtighten.
- If using a torque wrench, refer to the manufacturer's specifications for proper torque settings.

3. PostInstallation Check

- After installation, doublecheck that the screw is securely fastened.
- Perform a function check of the rifle to ensure everything operates smoothly.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste. Contact your local waste management facility for guidance.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the LuthAR AR15 A2 Upper Buttstock Screw, please reach out to the designated EU contact point provided with the product packaging.

Thank you for prioritizing safety and compliance while using the LuthAR AR15 A2 Upper Buttstock Screw. Your attention to these guidelines helps ensure a safe and enjoyable experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk