

AR-15 SEMI-AUTO TRIGGER - LUTH-AR AR-15 SEMI-AUTO TRIGGER

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

Luth-AR factory replacement trigger. Fits standard AR-15 rifles.



Attributes

- Name: [LUTH-AR AR-15 SEMI-AUTO TRIGGER](#)
- Manufacturer: [LUTH-AR](#)
- Product no.: 100028039
- Mfr. No.: LR20
- Style: Semi-Auto
- Weapon type: AR-15
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 25mm
- UPC: 859819007485

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- Startpage
- Safety Instruction Guide for AR15 SemiAuto Trigger
- About Us

Safety Instruction Guide for AR15 SemiAuto Trigger

Introduction

Thank you for choosing the LuthAR AR15 SemiAuto Trigger. This guide provides essential safety instructions and guidelines to ensure the safe use and handling of your trigger. Please read this document thoroughly before installation and use.

General Safety Guidelines

- Always treat your firearm as if it is loaded.
- Keep your finger off the trigger until you are ready to shoot.
- Store firearms and ammunition in a secure location, out of reach of children.
- Ensure that you are familiar with local laws and regulations regarding firearm ownership and usage.
- Regularly inspect your trigger and firearm for any signs of wear or damage.
- Use only compatible parts and accessories designed for your specific firearm model.

Specific Safety Precautions for Use

- Ensure that the firearm is pointed in a safe direction at all times.
- Do not modify the trigger or any other components of your firearm without consulting a qualified gunsmith.
- Be aware of your surroundings and ensure that you have a clear and safe shooting area.
- Always wear appropriate eye and ear protection when shooting.
- If you experience any malfunctions, cease use immediately and consult a qualified professional.

Instructions for Installation and Usage

1. Preparation:

- Ensure that your firearm is unloaded and the chamber is clear.
- Gather necessary tools for installation, including screwdrivers and wrenches.

2. Installation:

- Remove the existing trigger from your AR15 following the manufacturer's instructions.
- Carefully install the LuthAR AR15 SemiAuto Trigger according to the provided installation manual.
- Ensure that all screws and components are securely fastened.

3. Testing:

- After installation, perform a function check to ensure that the trigger operates correctly.
- Follow the manufacturer's guidelines for proper testing procedures.

4. Usage:

- Always follow safe shooting practices as outlined in the General Safety Guidelines.
- Familiarize yourself with the trigger's operation before engaging in live fire.

Disposal Instructions

- Dispose of the trigger and any associated components in accordance with local regulations.

- Do not dispose of any firearm parts in regular household waste. Contact local authorities for proper disposal methods.

Contact Information for Further Support

For safety inquiries or further assistance, please refer to the contact information provided by the manufacturer. Ensure that you have the product details available when seeking support.

By adhering to these safety guidelines and instructions, you contribute to a safer shooting experience. Always prioritize safety and responsibility when handling firearms.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk