

AR-15 TRIANGULAR HANDGUARD CAP - LUTH-AR AR-15 TRIANGULAR HANDGUARD CAP

[Rifle Parts](#) > [Forend & Handguard Parts](#) > [Handguard & Rail Hardware](#) > [Handguard Caps](#)

Luth-AR factory replacement Triangular Handguard Cap. Fits standard AR-15 rifles.



Attributes

- Name: [LUTH-AR AR-15 TRIANGULAR HANDGUARD CAP](#)
- Manufacturer: [LUTH-AR](#)
- Product no.: 100028052
- Mfr. No.: BL-19A
- Colour: Black
- Material: Steel
- Weapon type: AR-15
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 25mm

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for AR15 Triangular Handguard Cap
- About Us

Safety Instruction Guide for AR15 Triangular Handguard Cap

Introduction

Thank you for choosing the LuthAR AR15 Triangular Handguard Cap. This guide provides important safety information and instructions to ensure safe use and installation of the product. Please read this document carefully before use.

General Safety Guidelines

- Ensure the product is compatible with your AR15 rifle before installation.
- Always follow the manufacturer's instructions for installation and usage.
- Inspect the handguard cap for any damage before use. Do not use if damaged.
- Keep the product out of reach of children and vulnerable individuals.
- Report any safety concerns or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Use the handguard cap only for its intended purpose as a replacement part for AR15 rifles.
- Avoid exposing the handguard cap to extreme temperatures or harsh chemicals that may affect its integrity.
- Ensure that the handguard cap is securely attached before using the rifle.
- Do not modify the handguard cap in any way, as this may compromise safety and performance.
- Always wear appropriate safety gear when handling firearms, including eye and ear protection.

Instructions for Installation and Usage

1. Preparation

- Ensure the rifle is unloaded and pointed in a safe direction before beginning installation.
- Gather necessary tools, including a wrench or screwdriver if required.

2. Installation Steps

- Remove the existing handguard cap from the rifle by unscrewing or detaching it as per the manufacturer's instructions.
- Inspect the area where the new handguard cap will be installed for any debris or damage.
- Place the new LuthAR Triangular Handguard Cap in position.
- Securely attach the handguard cap using the appropriate screws or fasteners, ensuring it is tightened to the manufacturer's specifications.
- Doublecheck that the handguard cap is firmly in place before use.

3. Usage

- Always handle the rifle with care and follow standard firearm safety practices.
- Regularly inspect the handguard cap during routine maintenance to ensure it remains secure and undamaged.

Disposal Instructions

- Dispose of the handguard cap responsibly. If the product is no longer needed or is damaged beyond use, please follow local regulations for disposal of metal products.

- Consider recycling the product if possible, as it is made from steel.

Contact Information for Further Support

For any questions or concerns regarding the LuthAR AR15 Triangular Handguard Cap, please refer to the manufacturer's website or customer service for assistance.

Thank you for your attention to these safety guidelines. Your safety is our priority, and we appreciate your commitment to responsible firearm use.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk