

AR-15 EJECTION PORT COVER SPRING - LUTH-AR AR-15 EJECTION PORT COVER SPRING

[Home](#)

Luth-AR factory replacement Ejection Port Cover Spring. Fits standard AR-15 rifles.



Attributes

- Name: [LUTH-AR AR-15 EJECTION PORT COVER SPRING](#)
- Manufacturer: [LUTH-AR](#)
- Product no.: 100028059
- Mfr. No.: UR05
- Weapon type: AR-15
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 25mm
- UPC: 859819007843

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [AR15 EJECTION PORT COVER SPRING Safety Instruction Guide](#)
- [About Us](#)

AR15 EJECTION PORT COVER SPRING Safety Instruction Guide

Introduction

Thank you for purchasing the LuthAR Ejection Port Cover Spring for your AR15 rifle. This guide provides important safety instructions and information to ensure the safe use and installation of this product. Please read this guide carefully before use.

General Safety Guidelines

- Always follow the manufacturer's instructions for safe handling and usage of the product.
- Ensure that the product is compatible with your specific AR15 model.
- Handle all components of your firearm with care and respect, treating them as potentially dangerous.
- Store the Ejection Port Cover Spring in a safe place, out of reach of children and unauthorized users.
- Regularly inspect the Ejection Port Cover Spring and surrounding components for wear or damage.
- If you notice any defects or issues, do not use the product until it has been inspected and repaired by a qualified gunsmith.

Specific Safety Precautions for Use

- Ensure that the firearm is unloaded before performing any maintenance or installation.
- Use appropriate tools and wear safety gear when handling firearm components.
- Do not attempt to modify or alter the Ejection Port Cover Spring; doing so may compromise safety and functionality.
- Be aware of the environment in which you are handling your firearm to avoid accidents.
- If you are inexperienced or unsure about installation or usage, seek assistance from a qualified professional.

Instructions for Installation and Usage

Installation Steps

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools: a punch tool and a hammer.

2. Remove the Old Spring:

- Locate the existing Ejection Port Cover Spring.
- Use the punch tool to carefully remove the old spring from its housing.

3. Install the New Spring:

- Take the new LuthAR Ejection Port Cover Spring.
- Align it with the housing and gently insert it into place.
- Use the punch tool to secure it firmly, ensuring it is seated correctly.

4. Final Check:

- After installation, check the functionality of the Ejection Port Cover.
- Ensure that it opens and closes smoothly without any obstruction.

Usage Instructions

- After installation, regularly check the operation of the Ejection Port Cover during routine firearm maintenance.
- Always ensure that the Ejection Port Cover is functioning correctly before using the firearm.

Disposal Instructions

- Dispose of any old or damaged springs in accordance with local regulations.
- Do not dispose of the Ejection Port Cover Spring in regular household waste.
- Contact local authorities for proper disposal methods for firearm components.

Contact Information for Further Support

For any inquiries related to product safety, installation, or usage, please refer to the manufacturer's website or customer support resources. It is essential to have access to reliable information and assistance.

Conclusion

By following these safety instructions, you can ensure the proper use and installation of the LuthAR Ejection Port Cover Spring for your AR15 rifle. Always prioritize safety and consult professionals when in doubt. Thank you for choosing LuthAR.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk