

AR-15 EJECTION PORT COVER ASSEMBLY - LUTH-AR AR-15 EJECTION PORT COVER ASSEMBLY

[Rifle Parts](#) > [Receiver Parts](#) > [Ejection Port Cover Parts](#) > [Ejection Port Cover Assemblies](#)

Luth-AR factory replacement Ejection Port Cover Assembly. Fits standard AR-15 rifles.



Attributes

- Name: [LUTH-AR AR-15 EJECTION PORT COVER ASSEMBLY](#)
- Manufacturer: [LUTH-AR](#)
- Product no.: 100028060
- Mfr. No.: UR-05A
- Weapon type: AR-15
- Delivery weight: 0.045kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 51mm
- UPC: 859819007850

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [AR15 Ejection Port Cover Assembly Safety Instructions](#)
- [About Us](#)

AR15 Ejection Port Cover Assembly Safety Instructions

Introduction

Thank you for purchasing the LuthAR AR15 Ejection Port Cover Assembly. This product is designed to fit standard AR15 rifles, providing a reliable replacement for your firearm's ejection port cover. It is important to read and understand these safety instructions to ensure safe and proper use of the product.

General Safety Guidelines

- Always ensure that your firearm is unloaded before installing or handling the Ejection Port Cover Assembly.
- Follow all local, state, and federal laws regarding firearm ownership and modifications.
- Use this product only for its intended purpose; do not modify the assembly in any way.
- Keep the assembly out of reach of children and unauthorized users.
- Regularly inspect the assembly for any signs of wear or damage before use.
- In case of any malfunction or if you suspect the product is unsafe, discontinue use immediately and consult a qualified gunsmith.

Specific Safety Precautions for Use

- Ensure that the Ejection Port Cover Assembly is compatible with your specific AR15 model.
- When installing the assembly, avoid placing fingers near moving parts to prevent injury.
- Use appropriate tools for installation to avoid damaging the assembly or your firearm.
- Store the assembly in a cool, dry place when not in use to prevent corrosion or damage.
- If you experience any issues during installation or use, seek professional assistance.

Instructions for Installation and Usage

1. Preparation:

- Ensure your AR15 rifle is completely unloaded.
- Gather necessary tools (e.g., screwdriver, wrench) for installation.

2. Installation Steps:

- Remove the old ejection port cover if applicable.
- Align the new LuthAR Ejection Port Cover Assembly with the mounting points on the rifle.
- Secure the assembly using the appropriate screws or fasteners, ensuring it is tightly fitted.
- Test the assembly by manually operating the ejection port cover to ensure it opens and closes smoothly.

3. Usage:

- After installation, perform a function check on your AR15 to ensure all components are working correctly.
- Regularly clean the ejection port cover to prevent debris buildup, which could affect performance.

Disposal Instructions

- Dispose of any old or damaged parts in accordance with local regulations.
- If the Ejection Port Cover Assembly becomes damaged beyond repair, contact your local waste

management facility for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding the LuthAR AR15 Ejection Port Cover Assembly, please refer to the product packaging or visit the manufacturer's website for additional support.

By following these safety instructions, you can ensure a safe and effective experience with your LuthAR AR15 Ejection Port Cover Assembly. Always prioritize safety when handling firearms and their components.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk