


AIMPOINT PRO LEAP ULTRALIGHT MOUNT - SCALARWORKS

AIMPOINT PRO 1.57" LEAP/02 MOUNT

[Optics & Mounting](#) > [Electronic Sights](#) > [Mounting Hardware](#)

Impervious To Recoil - Retains Optic s Zero After Many Remove/Reinstall Cycles

The Scalarworks team engineered their Aimpoint PRO Leap Mount to be lighter, smaller, sleeker, and stronger than a traditional QR red dot mount. The goal was to create an Aimpoint mount that would not lose zero when the mount/optic unit is removed and reinstalled on the firearm multiple times. To test it, Scalarworks staff installed an Aimpoint PRO on an FN SCAR 17 (7.62 NATO chambering) with a Leap mount and fired ten 10-round strings, removing and reinstalling the Leap Mount between each string. The result? After the 100th round, the optic's zero had not moved at all from its original position. Goal achieved. The Scalarworks PRO Leap Mount can be used with any Aimpoint red dot with a 30mm tube, including the Patrol Rifle Optic (PRO), ACO, CompM2, CompM3, and similar 30mm red dots from other manufacturers. Machined from ultra-strong, ultra-light 7075 T6 aluminum alloy Matte black hardcoat anodized finish Tool-free mounting to MIL-STD 1913 Picatinny rails Recoil-proof ball-detent locking thumbscrew clamp won't let go of the rail Clamp automatically adapts to variations in rail spec No protruding knobs or levers to snag on other gear or vegetation Lower-Third Co-Witness (center of optic 40mm above rail) The Aimpoint PRO Leap Mount is fitted with Scalarworks' unique hinged ring that wraps around the optic body and automatically provides even pressure to lock it in place without all the tedious and imprecise setup traditional rings require. Two steel screws provide even tension and serve as structural elements, making the entire ring assembly extremely rigid - and secure.



Attributes

- Name: [SCALARWORKS AIMPOINT PRO 1.57" LEAP/02 MOUNT](#)
- Manufacturer: [SCALARWORKS](#)
- Product no.: 100029281
- Mfr. No.: SW0210
- Colour: Matte Black
- Delivery weight: 0.045kg
- Shipping height: 114mm
- Shipping width: 76mm
- Shipping length: 51mm
- UPC: 867442000070

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for AIMPOINT PRO LEAP ULTRALIGHT MOUNT SCALARWORKS AIMPOINT PRO 1.57" LEAP/02 MOUNT](#)
- [About Us](#)

Safety Instruction Guide for AIMPOINT PRO LEAP ULTRALIGHT MOUNT SCALARWORKS AIMPOINT PRO 1.57" LEAP/02 MOUNT

Introduction

Thank you for choosing the AIMPOINT PRO Leap Ultralight Mount by Scalarworks. This product has been engineered to provide a reliable and secure mounting solution for your Aimpoint red dot sight. Please read this safety instruction guide carefully to ensure safe and proper use of the product.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always follow the manufacturer's instructions for installation and use.
- Regularly inspect the mounting system for wear or damage.
- If you notice any defects or issues, cease use immediately and consult a professional.
- Keep the product out of reach of children and vulnerable individuals.
- Report any unsafe conditions or accidents involving this product to the relevant authorities.

Specific Safety Precautions for Use

• Installation Precautions:

- Ensure the firearm is unloaded before installation.
- Use appropriate tools for installation to avoid damage to the mount or the firearm.
- Do not overtighten screws; follow the manufacturer's torque specifications.

• Usage Precautions:

- Do not use the mount if any components are damaged or missing.
- Regularly check the zero of your optic after removing and reinstalling the mount.
- Avoid using the mount in extreme conditions unless specified by the manufacturer.

• Maintenance Precautions:

- Clean the mount regularly to ensure optimal performance.
- Store the mount in a dry, cool place when not in use.

Instructions for Installation and Usage

Installation Steps

1. Preparation:

- Ensure that the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools (if applicable).

2. Mounting the Aimpoint PRO:

- Align the Aimpoint PRO with the Scalarworks Leap Mount.
- Secure the mount onto the MILSTD 1913 Picatinny rail using the toolfree thumbscrew clamp.
- Ensure that the clamp adapts to the rail without any protruding knobs or levers.

3. **Tightening:**

- Tighten the locking thumbscrew clamp until secure. Ensure it is snug but not overtightened.

4. **Final Checks:**

- Verify that the optic is securely mounted and does not move.
- Check the zero of the optic after installation.

Usage Steps

1. **Before Use:**

- Confirm that the mount and optic are properly installed and secure.
- Ensure that the firearm is in a safe condition.

2. **During Use:**

- Monitor the performance of the mount during shooting.
- Check for any movement or loosening of the mount after firing.

3. **PostUse:**

- Inspect the mount for any signs of wear or damage.
- Clean the mount as needed.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of in regular household waste.
- Consider recycling options for aluminum components.

Contact Information for Further Support

For any inquiries regarding safety or product support, please refer to the manufacturer or authorized dealer for assistance.

By following these safety instructions, you can ensure the safe and effective use of your AIMPOINT PRO Leap Ultralight Mount. Thank you for your attention to safety and responsible use.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk