

3 PRONGED FLASH HIDER WRENCH - Thordsen Customs 3 PRONGED FLASH HIDER WRENCH

[Gunsmith Tools](#) > [Rifle Tools](#) > [Wrenches](#)

This 3 Pronged Flash Hider Wrench fits in the nose of a 3 Pronged Flash Hider (Such as our SKU# 5044) making it the perfect installation tool for installing our BD-180 in combination with the 3 Prong Flash Hider. Made from 41-40 Steel Forged from chrome vanadium alloy steel Heat treated to Rockwell 45 Limited Lifetime Warranty



Attributes

- Name: [Thordsen Customs 3 PRONGED FLASH HIDER WRENCH](#)
- Manufacturer: [Thordsen Customs](#)
- Product no.: 100029374
- Mfr. No.: 5418
- Delivery weight: 0.005kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 25mm

Item details

Made in USA

Table of Contents

- Startpage
- 3 PRONGED FLASH HIDER WRENCH SAFETY INSTRUCTIONS
- About Us

3 PRONGED FLASH HIDER WRENCH SAFETY INSTRUCTIONS

Introduction

Thank you for purchasing the 3 Pronged Flash Hider Wrench from Thordsen Customs. This tool is designed for safe and efficient installation of the BD180 in combination with the 3 Prong Flash Hider. Please read this safety instruction guide carefully to ensure safe usage and compliance with EU regulations.

General Safety Guidelines

- Ensure safe use of the wrench by following all instructions.
- Always inspect the tool for damage before use. Do not use if damaged.
- Keep the wrench out of reach of children and vulnerable individuals.
- Use the wrench only for its intended purpose as described in this guide.
- Report any unsafe products or incidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when using the wrench.
- Do not apply excessive force when using the wrench to avoid personal injury or damage to the tool.
- Ensure that the 3 Pronged Flash Hider is securely fastened before attempting to install or remove it with the wrench.
- Use the wrench in a welllit area to ensure visibility and control.
- Do not use the wrench for any application other than the installation or removal of the 3 Pronged Flash Hider.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and materials before starting the installation.
- Ensure that the working area is clean and free from obstructions.

2. Using the Wrench:

- Insert the 3 Pronged Flash Hider Wrench into the nose of the 3 Pronged Flash Hider.
- Turn the wrench clockwise to tighten or counterclockwise to loosen the Flash Hider.
- Apply steady, even pressure while turning the wrench. Avoid sudden jerks or excessive force.

3. PostInstallation:

- After installation, doublecheck that the Flash Hider is securely attached.
- Store the wrench in a safe place after use, away from children.

Disposal Instructions

- Dispose of the wrench responsibly at a designated recycling facility or according to local regulations.
- Do not dispose of the wrench in household waste.

Contact Information for Further Support

For safety inquiries or additional support, please refer to the manufacturer's contact details provided with the product packaging or visit the official website of Thordsen Customs.

Thank you for choosing Thordsen Customs. Your safety is our priority.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk