

VICKERS EXTENDED MAGAZINE RELEASE FOR GLOCK® 43 - VICKERS TACTICAL EXT MAG RELEASE, GLOCK 43, GLOCK GREEN

[Handgun Parts](#) > [Frame Parts](#) > [Magazine Release Parts](#) > [Magazine Releases](#)

Upgraded Part Helps You Make Fast Mag Changes When the Pressure's On

The Vickers Tactical GMR-006 Extended Magazine Release from Tangodown is a simple, drop-in upgrade for the Glock® 43 that makes it easy for the shooter to drop the magazine quickly under stress. Unlike the small factory part that causes many shooters to shift their grip in order to operate the release, the Vickers Tactical button is optimized for fast, positive operation regardless of the size or length of your thumb. The deeply serrated contact surface ensures that once you locate the button, your thumb will not slip, even if your hand is wet. Made of tough reinforced molded polymer Easy to install in a few minutes Requires no other alterations required to pistol Available in four distinctive colors The GMR-006 extended mag release is contoured so it's easy to locate by feel, while the same time it resists unintentional activation, such as when you place your G43 on a hard surface. The Vickers Tactical extended magazine release for Glock 43® is also ambidextrous. Both characteristics provide a valuable advantage on this extremely compact concealed carry pistol.



Attributes

- Name: [VICKERS TACTICAL EXT MAG RELEASE, GLOCK 43, GLOCK GREEN](#)
- Manufacturer: [TANGODOWN](#)
- Product no.: 100030594
- Mfr. No.: GMR00643GG
- Finish: Green
- Make: Glock
- Model: 43
- Delivery weight: 0.045kg
- Shipping height: 38mm
- Shipping width: 76mm
- Shipping length: 165mm
- UPC: 855729100131

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [Vickers Tactical Extended Magazine Release for Glock® 43 Safety Instructions](#)
- [About Us](#)

Vickers Tactical Extended Magazine Release for Glock® 43 Safety Instructions

Introduction

Thank you for choosing the Vickers Tactical GMR006 Extended Magazine Release for your Glock® 43. This product is designed to enhance your shooting experience by providing a more accessible and efficient way to release the magazine. To ensure your safety and the proper use of this product, please read and follow the safety instructions and guidelines outlined in this document.

General Safety Guidelines

- Ensure that your Glock® 43 is unloaded before installing or handling the magazine release.
- Always treat firearms as if they are loaded, even if you believe they are not.
- Keep the firearm pointed in a safe direction at all times.
- Store the product and firearm in a secure location, out of reach of children and unauthorized users.
- Do not use the magazine release if it appears damaged or if you suspect it may not function correctly.
- Be aware of your surroundings and ensure that no one is in the line of fire when operating your firearm.

Specific Safety Precautions for Use

- The Vickers Tactical Extended Magazine Release is designed for use with the Glock® 43 only. Do not attempt to use it with other models or brands.
- Ensure that your hands are dry and free of any substances that may cause slipping when operating the magazine release.
- Avoid placing the firearm on hard surfaces where the magazine release may be unintentionally activated.
- Always verify that the magazine is properly seated and the firearm is ready for use before engaging in shooting activities.
- If you experience any issues with the magazine release, cease use immediately and consult a qualified gunsmith or contact customer support for assistance.

Instructions for Installation and Usage

Installation Steps

1. **Ensure Safety:** Confirm that your Glock® 43 is completely unloaded.
2. **Remove the Existing Magazine Release:**
 - Locate the factory magazine release button on your Glock® 43.
 - Use a suitable tool to push in the retaining pin and remove the factory magazine release.
3. **Install the Vickers Tactical Extended Magazine Release:**
 - Align the Vickers Tactical magazine release with the opening on the Glock® 43.
 - Push the release into place until you hear a click, indicating it is securely installed.
4. **Test Functionality:**
 - With the firearm still unloaded, test the magazine release by pressing the button to ensure it operates smoothly.

Usage Guidelines

- To release the magazine, press the Vickers Tactical Extended Magazine Release button with your thumb.
- Practice using the magazine release in a safe environment to become familiar with its operation.
- After installation, check the magazine release regularly for any signs of wear or damage.

Disposal Instructions

When disposing of the Vickers Tactical Extended Magazine Release, follow these guidelines:

- If the product is damaged or no longer usable, dispose of it in accordance with local regulations for plastic waste.
- Do not dispose of the product in a manner that could pose a safety risk to others.
- Ensure that no parts of the magazine release are accessible to children or unauthorized individuals.

Contact Information for Further Support

For any questions or concerns regarding the Vickers Tactical Extended Magazine Release, please consult your local authorized dealer or a qualified gunsmith for assistance. Always prioritize safety and ensure you are following all local laws and regulations regarding firearm accessories.

Thank you for your attention to these safety instructions. Enjoy your enhanced shooting experience with the Vickers Tactical GMR006 Extended Magazine Release for Glock® 43.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at