

# LOAD-MASTER PROGRESSIVE PRESSES - LEE PRECISION 44 SPECIAL/MAGNUM LOAD-MASTER PROGRESSIVE PRESS

[Reloading](#) > [Reloading Presses](#) > [Progressive Presses](#)

The Lee Load-Master progressive 5-hole reloading kit includes full length sizing die, powder through expanding die, bullet seating die, turret, shell plate, Auto-Drum Powder Measure, case feeder and primer feed. The Load-Master Progressive Press Only does not include Case feeder, Dies, Shell Plate, Primer Feed or Powder measure. These items must be purchased separately.



## Attributes

- Name: [LEE PRECISION 44 SPECIAL/MAGNUM LOAD-MASTER PROGRESSIVE PRESS](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 100032126
- Mfr. No.: 90943
- Cartridge: 44 Magnum,44 Special
- Delivery weight: 6.872kg
- Shipping height: 229mm
- Shipping width: 279mm
- Shipping length: 483mm
- UPC: 734307909437

## Item details

Made in USA

# Table of Contents

- Startpage
- Safety Instructions for the Lee LoadMaster Progressive Press
- About Us

# Safety Instructions for the Lee LoadMaster Progressive Press

## Introduction

Thank you for choosing the Lee LoadMaster Progressive Press for your reloading needs. This guide provides essential safety instructions to ensure the safe and effective use of your reloading press. Please read this guide thoroughly before using the product.

## General Safety Guidelines

- **Product Safety:** Always ensure that you are using the LoadMaster Progressive Press in a safe manner. Follow all instructions provided in this guide.
- **Enhanced Recalls:** Stay informed about any recalls or safety notices related to this product. Check the EU Safety Gate platform for updates.
- **Online Shopping:** If you purchased this product online, ensure that the retailer complies with safety requirements.
- **Special Consumer Focus:** This product is not intended for use by children. Keep it out of their reach.
- **EU Contact Point:** For any safety inquiries, refer to the designated EU contact point for assistance.
- **Rapid Alerts:** Be aware that updates on unsafe products can be found on the Safety Gate system.

## Specific Safety Precautions for Use

- **Read the Manual:** Always read and understand the user manual before operating the press.
- **Wear Safety Gear:** Use appropriate safety gear, including safety glasses and gloves, when reloading.
- **Check for Damage:** Inspect the press and all components for any signs of damage before each use.
- **Use Proper Components:** Only use recommended dies, shell plates, and other components with the LoadMaster Progressive Press.
- **Avoid Distractions:** Do not operate the press when you are tired, distracted, or under the influence of substances.
- **Keep Work Area Clean:** Maintain a clean and organized workspace to reduce the risk of accidents.
- **Store Safely:** Store the press and all reloading components in a secure location, away from children and unauthorized users.

## Instructions for Installation and Usage

### • Installation:

1. Choose a stable and level surface for the press installation.
2. Securely mount the press to the workbench using the provided hardware.
3. Ensure that the press is firmly attached to prevent movement during operation.

### • Setup:

1. Install the fulllength sizing die, powder through expanding die, and bullet seating die as per the user manual.
2. Attach the turret and shell plate securely.
3. Set up the AutoDrum Powder Measure according to the instructions provided.
4. Connect the case feeder and primer feed if applicable.

### • Usage:

1. Follow the stepbystep reloading instructions provided in the user manual.

2. Always doublecheck measurements and settings before starting the reloading process.
3. Monitor the operation closely and stop immediately if any unusual sounds or movements occur.
4. Do not overload the press beyond its specified limits.

## **Disposal Instructions**

- Dispose of any unused or expired reloading components in accordance with local regulations.
- Recycle packaging materials where possible.
- Ensure that any hazardous materials are disposed of properly to avoid environmental harm.

## **Contact Information for Further Support**

For further assistance with the Lee LoadMaster Progressive Press, please refer to the manufacturer's website or contact the designated EU contact point for safety inquiries.

Thank you for prioritizing safety while using your Lee LoadMaster Progressive Press. Happy reloading!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)