

ACR HANDGUARDS M-LOK - ACR HANDGUARD ALUMINUM 12.5" M-LOK FDE

[Rifle Parts](#) > [Build Kits](#) > [Handguards & Rails](#)

Outfit Your Bushmaster ACR the Right Way

Improve the look, feel and versatility of your Bushmaster ACR with the Midwest Industries ACR M-LOK Handguard, designed with a host of modern features that will bring your ACR alongside today's cutting-edge modern sporting rifles. With up to 48 different M-LOK attachment points, the rail provides unprecedented flexibility in mounting lights, lasers and other accessories.



Attributes

- Name: [ACR HANDGUARD ALUMINUM 12.5" M-LOK FDE](#)
- Manufacturer: [MIDWEST INDUSTRIES](#)
- Product no.: 100032705
- Mfr. No.: MI-ACR-12.5-FDE
- Color: Flat Dark Earth
- Length: 12.5
- Material: Aluminum
- Style: M-LOK
- Delivery weight: 0.433kg
- Shipping height: 102mm
- Shipping width: 102mm
- Shipping length: 362mm
- UPC: 816537011040

Item details

Made in USA

US export classification: 0A501.y.1

Table of Contents

- Startpage
- ACR MLOK Handguard Safety Instruction Guide
- About Us

ACR MLOK Handguard Safety Instruction Guide

Introduction

Thank you for choosing the ACR MLOK Handguard manufactured by Midwest Industries. This guide provides essential safety instructions and information to ensure the safe and effective use of your new handguard. Please read this document carefully before installation and use.

General Safety Guidelines

- Always ensure that the product is installed correctly before use.
- Inspect the handguard for any visible damage before installation.
- Keep the handguard away from children and vulnerable individuals.
- Follow all local laws and regulations regarding firearm accessories.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that the handguard is compatible with your Bushmaster ACR model.
- Do not exceed the weight limit of the handguard when attaching accessories.
- Avoid using the handguard in extreme temperatures or adverse weather conditions.
- Regularly check all attachments and mounting points for security and stability.
- Use appropriate protective gear when handling firearms.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools for installation, including a torque wrench and the appropriate hex keys.
- Ensure your workspace is clean and free of distractions.

2. Installation:

- Remove the existing handguard from your Bushmaster ACR by following the manufacturer's instructions.
- Align the ACR MLOK Handguard with the mounting points on your rifle.
- Secure the handguard using the provided mounting hardware.
- Use a torque wrench to tighten the screws to the manufacturer's recommended specifications.

3. Usage:

- Once installed, familiarize yourself with the MLOK attachment points.
- Attach accessories such as lights or lasers securely, ensuring they are firmly fixed.
- Regularly inspect the handguard and attachments during use for any signs of wear or looseness.

Disposal Instructions

- Dispose of the ACR MLOK Handguard in accordance with local regulations.
- Recycle materials where applicable, ensuring that any metal components are properly processed.
- Do not dispose of the handguard in regular household waste if it contains hazardous materials.

Contact Information for Further Support

For any questions or concerns regarding the ACR MLOK Handguard, please refer to the manufacturer's website or customer support resources. It is important to have access to assistance for any safety inquiries or product issues.

Thank you for your attention to these safety guidelines. Your safety and satisfaction are our top priorities.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at