

AR-15 PISTOL PIGTAIL GAS TUBE - PHASE 5 TACTICAL AR-15 PISTOL PIGTAIL GAS TUBE

[Rifle Parts](#) > [Gas System Parts](#) > [Gas Tubes](#)

Holds the Rifle Closely and Securely

If your AR-15 pistol with a 7.5 inch barrel has timing issues due to being over-gassed, the Phase 5 Pistol Pigtail Gas Tube is the solution to your problem. The Phase 5 Pistol Pigtail Gas Tube design adds length to an otherwise short gas tube, having the effect of simulating a standard cycle time. The Phase 5 Pistol Pigtail Gas Tube is a quick and inexpensive way to solve your timing problem, because it frequently tames even the most over-gassed AR pistols without the need to experiment with buffer weights, different carriers, etc. A more mil-spec pistol means a more reliable pistol. Loop diameter: 1.46 to 1.56 inches Material: Stainless steel The Phase 5 Pistol Pigtail Gas Tube works best under rails with an inside diameter of at least 1.65 inches, and fits all barrels using a pistol length gas system with an outer diameter of 1 inch or less.



If your AR-15 pistol with a 7.5 inch barrel has timing issues due to being over-gassed, the Phase 5 Pistol Pigtail Gas Tube is the solution to your problem. The Phase 5 Pistol Pigtail Gas Tube design adds length to an otherwise short gas tube, having the effect of simulating a standard cycle time. The Phase 5 Pistol Pigtail Gas Tube is a quick and inexpensive way to solve your timing problem, because it frequently tames even the most over-gassed AR pistols without the need to experiment with buffer weights, different carriers, etc. A more mil-spec pistol means a more reliable pistol. Loop diameter: 1.46 to 1.56 inches Material: Stainless steel The Phase 5 Pistol Pigtail Gas Tube works best under rails with an inside diameter of at least 1.65 inches, and fits all barrels using a pistol length gas system with an outer diameter of 1 inch or less.

Attributes

- Name: [PHASE 5 TACTICAL AR-15 PISTOL PIGTAIL GAS TUBE](#)
- Manufacturer: [PHASE 5 TACTICAL](#)
- Product no.: 100036023
- Mfr. No.: PIGTAIL
- Gas System Length: Pistol
- Weapon type: AR-15
- Delivery weight: 0.036kg
- Shipping height: 25mm
- Shipping width: 102mm
- Shipping length: 203mm
- UPC: 813318020437

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [AR15 Pistol Pigtail Gas Tube Safety Instructions](#)
- [About Us](#)

AR15 Pistol Pigtail Gas Tube Safety Instructions

Introduction

Thank you for choosing the Phase 5 Tactical AR15 Pistol Pigtail Gas Tube. This product is designed to enhance the performance of your AR15 pistol with a 7.5 inch barrel by addressing timing issues that may arise due to overgassing. To ensure safe use and optimal performance, please read and follow all safety instructions outlined in this guide.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always handle firearms safely and responsibly.
- Keep the gas tube and surrounding areas clean and free of obstructions.
- Regularly inspect the gas tube for any signs of wear or damage.
- Store the gas tube in a cool, dry place when not in use.
- If you are unfamiliar with firearm maintenance, seek assistance from a qualified gunsmith.

Specific Safety Precautions for Use

- Use only with AR15 pistols that have a 7.5 inch barrel and a pistol length gas system.
- Ensure that the outer diameter of the barrel is 1 inch or less to guarantee proper fit.
- Verify that the inside diameter of the rail is at least 1.65 inches for optimal performance.
- Avoid using the gas tube with any modifications that may interfere with its operation.
- Do not attempt to disassemble or modify the gas tube.

Instructions for Installation and Usage

1. Preparation

- Ensure that your firearm is unloaded and pointed in a safe direction.
- Gather all necessary tools for installation, including a wrench and any applicable mounting hardware.

2. Installation Steps

- Remove the existing gas tube from your AR15 pistol following the manufacturer's instructions.
- Carefully insert the Phase 5 Pistol Pigtail Gas Tube into the gas block.
- Align the gas tube properly to ensure it fits securely.
- Use the appropriate tools to tighten any mounting hardware, ensuring a snug fit without overtightening.

3. PostInstallation Check

- Inspect the installation to confirm that the gas tube is securely in place.
- Perform a function check to ensure that the gas system operates correctly.

4. Usage Tips

- Monitor the firearm's performance during initial use to identify any potential issues.
- If problems persist or new issues arise, consult a qualified gunsmith for assistance.

Disposal Instructions

- Dispose of the gas tube in accordance with local regulations.
- Do not dispose of the gas tube in regular household waste.
- If the gas tube is damaged or no longer usable, contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding the Phase 5 Tactical AR15 Pistol Pigtail Gas Tube, please refer to the manufacturer's contact information provided with your product packaging or visit the manufacturer's website for further assistance.

By following these safety instructions, you can help ensure a safe and enjoyable experience with your AR15 Pistol Pigtail Gas Tube. Always prioritize safety and responsible handling of firearms.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk