

AR ANTI-WALK PINS - STRIKE INDUSTRIES AR ANTI-WALK PINS

[Rifle Parts](#) > [Triggers Parts](#) > [Hammer Parts](#) > [Hammer Pins](#)

The SI Anti-rotation/Anti-walk pin kit adds an extra degree of security to prevent your pins from walking out under fire or harsh use. Toolless installation and disassembly allows for ease of maintenance, with no small screws to back out or become lost. The smooth polished surface allows for a smoother trigger pull with standard trigger groups, and the additional retention is essential for drop in trigger packs. QPQ nitrided high strength steel prevents corrosion and wear providing for a lifetime of use.



Attributes

- Name: [STRIKE INDUSTRIES AR ANTI-WALK PINS](#)
- Manufacturer: [STRIKE INDUSTRIES](#)
- Product no.: 100037084
- Mfr. No.: SI-AR-AWP
- Weapon type: AR-15
- Delivery weight: 0.013kg
- Shipping height: 6mm
- Shipping width: 108mm
- Shipping length: 152mm
- UPC: 708747546866

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for AR AntiWalk Pins by Strike Industries](#)
- [About Us](#)

Safety Instruction Guide for AR AntiWalk Pins by Strike Industries

Introduction

Thank you for choosing the AR AntiWalk Pins by Strike Industries. This product is designed to enhance the security of your firearm by preventing the pins from walking out during use. To ensure your safety and the longevity of the product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure that the AR AntiWalk Pins are compatible with your firearm model before installation.
- Always handle firearms with care and follow standard firearm safety practices.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the pins for wear or damage before use.
- If you notice any irregularities or issues, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

• Installation Precautions:

- Ensure the firearm is unloaded before beginning installation.
- Wear safety glasses to protect your eyes during installation.

• Operational Precautions:

- Do not use the firearm if the pins are not securely installed.
- Be aware of your surroundings and ensure a safe environment when using the firearm.

• Maintenance Precautions:

- Regularly clean the pins and surrounding areas to prevent dirt and debris buildup.
- Inspect the pins for corrosion or wear, especially after exposure to harsh conditions.

Instructions for Installation and Usage

1. Installation:

- Ensure that your firearm is completely unloaded.
- Remove the existing pins from the trigger assembly.
- Align the AR AntiWalk Pins with the trigger assembly holes.
- Press the pins into place until they are fully seated.
- Verify that the pins are secure and do not move.

2. Usage:

- Once installed, operate your firearm as you normally would, ensuring that the trigger functions correctly.
- Monitor the performance of the pins during use, paying attention to any unusual movements.

3. Disassembly (if needed):

- Ensure the firearm is unloaded before disassembly.

- Carefully remove the AR AntiWalk Pins by pushing them out from the opposite side of the trigger assembly.

Disposal Instructions

- Dispose of the AR AntiWalk Pins in accordance with local regulations regarding metal waste.
- Do not dispose of the product in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the AR AntiWalk Pins, please consult your local dealer or contact the manufacturer directly for support.

By following these guidelines, you can ensure safe and effective use of the AR AntiWalk Pins. Thank you for prioritizing safety and compliance with EU General Product Safety Regulations.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk