

JITTERPLUG FOR GLOCK® - STRIKE INDUSTRIES JITTERPLUG FOR GLOCK

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Spring Guide Rods](#)

The SI JitterPlug is a drop-in component that installs in a stock polymer guide rod for compact and full-size Glocks. Installed between the guide rod and the front of the lower locking lugs, the SI-GJP increases spring tension on the barrel and slide, improving lockup feel and removing that annoying Glock barrel rattle.



Attributes

- Name: [STRIKE INDUSTRIES JITTERPLUG FOR GLOCK](#)
- Manufacturer: [STRIKE INDUSTRIES](#)
- Product no.: 100037258
- Mfr. No.: SI-GJP
- Model: 17,19,22,23,31,32,37,38
- Weapon type: Glock
- Delivery weight: 0.006kg
- Shipping height: 6mm
- Shipping width: 108mm
- Shipping length: 152mm
- UPC: 708747545289

Item details

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for JITTERPLUG FOR GLOCK®
- About Us

Safety Instruction Guide for JITTERPLUG FOR GLOCK®

Introduction

Thank you for choosing the SI JitterPlug for your Glock® firearm. This product is designed to enhance the performance of your Glock® by improving the lockup feel and reducing barrel rattle. It is important to read and understand these safety instructions to ensure safe and effective use of the JitterPlug.

General Safety Guidelines

- Ensure that the JitterPlug is installed correctly to avoid any operational issues.
- Always follow safety protocols when handling firearms.
- Keep the JitterPlug and all firearm components out of reach of children and unauthorized users.
- Regularly inspect your firearm and its components for wear or damage.
- If you notice any irregularities during operation, discontinue use and consult a qualified gunsmith.

Specific Safety Precautions for Use

- Only use the JitterPlug with compatible Glock® models: 37, 17, 19, 22, 23, 31, 32, 38.
- Do not use the JitterPlug if it appears damaged or if any parts are missing.
- Ensure that your firearm is unloaded before installing or removing the JitterPlug.
- Be aware that modifications to your firearm may affect its warranty and performance.
- Follow all local laws and regulations regarding firearm modifications.

Instructions for Installation and Usage

1. Preparation

- Ensure your Glock® is unloaded. Remove the magazine and check the chamber.
- Gather necessary tools: a flathead screwdriver and a clean cloth.

2. Installation Steps

- Remove the slide from the frame of the Glock®.
- Carefully remove the stock polymer guide rod from the slide.
- Clean the area around the guide rod and the lower locking lugs with a clean cloth.
- Insert the SI JitterPlug between the guide rod and the front of the lower locking lugs.
- Reinstall the guide rod into the slide, ensuring it is seated correctly.
- Reattach the slide to the frame of the Glock®.

3. PostInstallation Checks

- Perform a function check to ensure the firearm operates correctly.
- Check for any unusual noises or movement when cycling the slide.
- If any issues are detected, remove the JitterPlug and consult a qualified gunsmith.

Disposal Instructions

- Dispose of the JitterPlug in accordance with local regulations.
- Do not dispose of the JitterPlug in household waste.
- Consider recycling options if available in your area.

Contact Information for Further Support

For any questions or concerns regarding the JITTERPLUG FOR GLOCK®, please refer to the manufacturer's website or contact their customer support for assistance.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk