

GUIDE ROD ASSEMBLY FOR GLOCK® 19 - RIVAL ARMS GUIDE ROD ASSEMBLY FOR GLOCK® 19 GEN 3 STAINLESS

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Spring Guide Rods](#)

Experienced shooters realize plastic guide rods can chip, crack, or break resulting in feeding or ejection failures, flex can also contribute to accuracy problems. Rival Arms™ Guide Rod Assemblies address all of these issues and will provide you a lifetime of reliable service.



Attributes

- Name: [RIVAL ARMS GUIDE ROD ASSEMBLY FOR GLOCK® 19 GEN 3 STAINLESS](#)
- Manufacturer: [RIVAL ARMS](#)
- Product no.: 100038497
- Mfr. No.: RA-RA50G201S
- Model: 19,Gen 3
- Weapon type: Glock
- Delivery weight: 0.045kg
- Shipping height: 38mm
- Shipping width: 76mm
- Shipping length: 114mm
- UPC: 788130027103

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- GUIDE ROD ASSEMBLY FOR GLOCK® 19 RIVAL ARMS
- About Us

GUIDE ROD ASSEMBLY FOR GLOCK® 19 RIVAL ARMS

Introduction

Thank you for choosing the Rival Arms Guide Rod Assembly for your Glock® 19 Gen 3. This guide is designed to help you understand the safe use, installation, and maintenance of your product in compliance with the EU General Product Safety Regulation (GPSR). Please read this guide carefully to ensure safe operation and optimal performance.

General Safety Guidelines

- Always ensure that the firearm is unloaded before installing or servicing the guide rod assembly.
- Inspect the guide rod assembly regularly for any signs of wear, damage, or malfunction.
- Do not use the guide rod assembly if you notice any cracks, chips, or other damage.
- Keep the product out of reach of children and unauthorized users.
- Follow all local laws and regulations regarding the use of firearms.
- Report any unsafe product incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure the guide rod assembly is compatible with your specific model of Glock® 19 Gen 3.
- Avoid using the guide rod assembly in extreme temperatures or environments that may cause it to degrade.
- Use only manufacturerapproved replacement parts to maintain optimal performance and safety.
- Do not modify the guide rod assembly in any way, as this may compromise safety and functionality.
- Be cautious when handling the firearm to prevent accidental discharge.

Instructions for Installation and Usage

1. Preparation:

- Ensure that the firearm is unloaded and pointed in a safe direction.
- Gather all necessary tools for installation.

2. Installation Steps:

- Remove the slide from the frame of the Glock® 19.
- Take out the existing guide rod assembly by carefully pulling it out of the slide.
- Insert the Rival Arms guide rod assembly into the slide, ensuring it fits snugly and securely.
- Reattach the slide to the frame, ensuring all components are aligned properly.

3. Usage:

- After installation, perform a function check to ensure the guide rod assembly operates correctly.
- Regularly inspect the assembly during routine maintenance to ensure it remains in good condition.

Disposal Instructions

- Dispose of any damaged or worn guide rod assemblies in accordance with local regulations for hazardous materials.
- Do not discard the guide rod assembly in regular household waste. Instead, contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the Rival Arms Guide Rod Assembly or its usage, please refer to the manufacturer's website or contact their customer service for assistance.

By following these guidelines, you can ensure the safe use and longevity of your Rival Arms Guide Rod Assembly for Glock® 19 Gen 3. Thank you for your attention to safety and responsible handling of your firearm.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk