

MINI CAMERA TRIPOD - LONGSHOT TARGET CAMERAS MINI CAMERA TRIPOD

[Optics & Mounting](#) > [Action Cameras](#) > [Accessories](#)

Rather than looking for a stable piece of ground for your target camera, it makes more sense to outfit your downrange system with a stable tripod that keeps it securely pointed at your target in all conditions. Enter the LONGSHOT Mini Camera Tripod. Not only is this Minim Camera Tripod designed to keep your camera pointed at the right spot for all-day shooting, it's also small and light enough to be easily carried into remote shooting spots.



Attributes

- Name: [LONGSHOT TARGET CAMERAS MINI CAMERA TRIPOD](#)
- Manufacturer: [LONGSHOT TARGET CAMERAS](#)
- Product no.: 100038724
- Mfr. No.: TV-AT100
- Delivery weight: 0.313kg
- Shipping height: 76mm
- Shipping width: 76mm
- Shipping length: 229mm
- UPC: 649070997652

Table of Contents

- Startpage
- Safety Instruction Guide for LONGSHOT Mini Camera Tripod
- About Us

Safety Instruction Guide for LONGSHOT Mini Camera Tripod

Introduction

Thank you for choosing the LONGSHOT Mini Camera Tripod. This guide provides essential safety information and instructions to ensure the safe and effective use of your tripod. Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure that the tripod is used on stable and level ground to prevent tipping or falling.
- Always check the integrity of the tripod before use. Look for any signs of wear or damage.
- Keep the tripod away from water and moisture to avoid damage.
- Do not exceed the weight limit specified by the manufacturer for your camera and accessories.
- Avoid using the tripod in extreme weather conditions, such as high winds or storms.
- Store the tripod in a dry place when not in use to prolong its lifespan.
- Report any safety concerns or incidents related to the tripod to the appropriate authorities.

Specific Safety Precautions for Use

- **Age Restrictions:** This product is not intended for use by children under the age of 12 without adult supervision.
- **Camera Attachment:** Ensure that your camera is securely attached to the tripod before use to prevent accidental drops.
- **Transporting:** When carrying the tripod, ensure that it is folded and secured to prevent injury.
- **Setup:** When setting up the tripod, ensure all legs are fully extended and locked in place before mounting your camera.
- **Monitoring:** Always monitor your equipment while in use to prevent theft or damage.

Instructions for Installation and Usage

1. Unfolding the Tripod:

- Remove the tripod from its carrying case.
- Carefully unfold each leg of the tripod. Ensure that each leg is fully extended and locked into place.

2. Adjusting the Height:

- Adjust the height of the tripod by loosening the locking mechanism on each leg.
- Extend or shorten the legs to the desired height, then retighten the locking mechanism to secure.

3. Attaching Your Camera:

- Locate the mounting plate on the tripod.
- Attach your camera to the mounting plate, ensuring it is securely fastened.
- Once attached, check that the camera is stable and secure.

4. Positioning the Tripod:

- Place the tripod on a stable surface, ensuring all three legs are firmly planted.
- Adjust the angle of the camera as needed for your shot.

5. Using the Tripod:

- Use the camera as you normally would while it is mounted on the tripod.
- Periodically check the stability of the tripod during use.

6. Dismantling the Tripod:

- After use, carefully remove your camera from the tripod.
- Loosen the locking mechanisms and fold the legs back into their original position.
- Store the tripod in its carrying case.

Disposal Instructions

When disposing of the LONGSHOT Mini Camera Tripod, please follow local regulations for electronic waste and plastic disposal. Do not dispose of the tripod in regular household waste. Consider recycling options available in your area.

Contact Information for Further Support

For any safety inquiries or concerns related to this product, please consult the manufacturer's website or contact your local consumer safety authority.

Thank you for your attention to these safety instructions. We hope you enjoy using your LONGSHOT Mini Camera Tripod safely and effectively!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk