

# GRIPCHANGER SHOOTING BAG - AREA 419 RAILCHANGER GRIPCHANGER

[Home](#)

This small, grippy, densely-filled bag is perfect for quick position building or for use in small portholes where a normal support bag wouldn't fit. About 1 pound in total weight and made with Armageddon Gears "Grippy" material, this bag provides you a nice platform when you need it quickly. Can be used alone or with the Area 419 RailChanger. A note on shooting bags: Most positional shooting bags are not filled firmly on purpose. The reason being a loose filled bag will fill in gaps, drape across obstacles, and create a more stable shooting platform than a firm filled bag.



## Attributes

- Name: [AREA 419 RAILCHANGER GRIPCHANGER](#)
- Manufacturer: [AREA 419](#)
- Product no.: 100039235
- Mfr. No.: 419-AG-GRIP
- Colour: Graphite
- Material: Sticky Fabric
- Delivery weight: 0.544kg
- Shipping height: 38mm
- Shipping width: 76mm
- Shipping length: 178mm
- UPC: 850002933321

## Item details

Made in USA

# Table of Contents

- [Startpage](#)
- [GRIPCHANGER SHOOTING BAG SAFETY INSTRUCTIONS](#)
- [About Us](#)

# GRIPCHANGER SHOOTING BAG SAFETY INSTRUCTIONS

## Introduction

Thank you for choosing the GRIPCHANGER Shooting Bag by AREA 419. This guide provides important safety instructions and guidelines to ensure safe and effective use of the product. Please read this document carefully before using the shooting bag.

## General Safety Guidelines

- Ensure the shooting bag is used only for its intended purpose as a support bag for shooting.
- Regularly inspect the bag for any signs of wear, damage, or defects before each use.
- Store the bag in a dry and clean environment to prevent deterioration of materials.
- Keep the shooting bag out of reach of children when not in use.
- Report any unsafe conditions or incidents related to the product to the appropriate authorities.

## Specific Safety Precautions for Use

- When using the shooting bag, ensure it is placed on a stable surface to prevent slipping or tipping.
- Avoid using the bag in extreme weather conditions that may affect its performance or safety.
- Do not overload the bag with excessive weight beyond its intended use.
- Be cautious when positioning the bag in small portholes or tight spaces to avoid injury.
- If using with the Area 419 RailChanger, ensure proper attachment and stability before use.

## Instructions for Installation and Usage

### 1. Setting Up the Bag:

- Remove the bag from its packaging and check for any visible damage.
- Place the bag on a flat, stable surface where you will be shooting.

### 2. Using the Bag:

- Position the bag to provide support for your shooting stance.
- Adjust the bag as needed to fill gaps and create a stable platform.
- If using with the Area 419 RailChanger, follow the manufacturer's instructions for attachment.

### 3. PostUse Care:

- After use, clean the bag with a damp cloth to remove dirt and debris.
- Allow the bag to dry completely before storing it.
- Store the bag in a cool, dry place to maintain its condition.

## Disposal Instructions

- When the shooting bag reaches the end of its life cycle, dispose of it in accordance with local regulations.
- Do not dispose of the bag in regular household waste if it contains materials that can be recycled.
- Consider donating the bag if it is still in usable condition.

## **Contact Information for Further Support**

For any questions or concerns regarding the GRIPCHANGER Shooting Bag, please refer to the manufacturer's website or contact the customer support team directly. Always ensure you have the product details at hand when seeking assistance.

Thank you for your attention to these safety instructions. Enjoy your shooting experience with the GRIPCHANGER Shooting Bag!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)