

"VICTORY" TRIGGER FOR RUGER™ PC CARBINE - TANDEMROSS VICTORY TRIGGER FOR RUGER® PC CARBINE® RED

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

At a glance: Flat-faced, textured design improves grip, control Post-travel adjustable Offers short, identical, repeatable trigger pulls The Ruger® PC Carbine™ is quickly gaining popularity among shooting sports competitors, especially with PCC competitions on the rise. The PC Carbine™ is a fantastic gun out of the box, but even a good gun can be made great! The new "Victory" Trigger for Ruger® PC Carbine™ is the ultimate competition PC Carbine™ upgrade. Modeled after our signature TANDEMROSS "Victory" Trigger product line, the new PC Carbine™ trigger features a textured, flat-faced design for better grip and control. The lightweight, skeletonized trigger design allows the shooter to pull straight back, making it easier to tell if you're pulling too far to the left or right. The trigger has very little pre-travel and is post-travel adjustable for a custom fit and function. The PCC trigger's flat-faced design allows the user to place their finger lower on the trigger face, improving leverage and lowering the feel of the trigger pull.



Attributes

- Name: [TANDEMROSS VICTORY TRIGGER FOR RUGER® PC CARBINE® RED](#)
- Manufacturer: [TANDEMROSS](#)
- Product no.: 100039446
- Mfr. No.: TK28N0301RED1
- Model: PC Carbine
- Style: Flat
- Weapon type: Ruger
- Delivery weight: 0.01kg
- Shipping height: 13mm
- Shipping width: 76mm
- Shipping length: 102mm
- UPC: 769498483503

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- Startpage
- Safety Instruction Guide for the VICTORY Trigger for Ruger PC Carbine
- About Us

Safety Instruction Guide for the VICTORY Trigger for Ruger PC Carbine

Introduction

Thank you for choosing the VICTORY Trigger for Ruger PC Carbine. This product is designed to enhance your shooting experience by providing improved grip, control, and trigger pull consistency. However, safety is paramount. This guide contains important safety instructions and guidelines to ensure the safe use of this product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the VICTORY Trigger is compatible with your Ruger PC Carbine before installation.
- Always handle firearms responsibly and in accordance with local laws and regulations.
- Keep the trigger and firearm out of reach of children and unauthorized users.
- Regularly inspect the trigger for wear or damage. Do not use if damaged.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about recall updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always ensure the firearm is unloaded before installing or adjusting the trigger.
- Avoid placing fingers on the trigger when not ready to shoot.
- Use protective eyewear and hearing protection when using the firearm.
- Do not modify the trigger or firearm beyond the manufacturer's specifications.
- Be aware of your surroundings and ensure a safe shooting environment.
- If you experience any malfunction or unusual behavior, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

Installation Instructions

1. **Preparation:** Ensure the Ruger PC Carbine is unloaded and pointed in a safe direction.
2. **Remove the Old Trigger:** Follow the manufacturer's instructions to safely remove the existing trigger.
3. **Install the VICTORY Trigger:**
 - Align the new trigger in the trigger assembly.
 - Secure it according to the manufacturer's specifications.
4. **Adjust the Trigger:** Use the posttravel adjustment feature to customize the trigger pull to your preference.
5. **Test the Trigger:** Before use, ensure the trigger operates smoothly and as intended.

Usage Instructions

- Always follow basic firearm safety rules when using the Ruger PC Carbine with the VICTORY Trigger.
- Check the trigger pull before each session to ensure it meets your comfort and safety levels.
- Practice regularly to become familiar with the trigger's feel and response.

Disposal Instructions

- Dispose of the VICTORY Trigger and any associated packaging in accordance with local regulations.
- Do not dispose of the product in regular household waste. Instead, use designated recycling or hazardous waste disposal methods as applicable.

Contact Information for Further Support

For any inquiries regarding the VICTORY Trigger or safety concerns, please refer to the manufacturer's website or customer service resources available in your region.

Thank you for prioritizing safety while enjoying your shooting experience with the VICTORY Trigger for Ruger PC Carbine.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk