

"VICTORY" TRIGGER FOR KELTEC PMR30/CMR30/CP33 - VICTORY TRIGGER FOR KELTEC PMR/CMR-30 BLACK

[Handgun Parts](#) > [Trigger Group Parts](#) > [Trigger Parts](#) > [Triggers](#)

A a glance: Flat-faced, skeletonized design for better control and feel Textured trigger face offers a no-slip grip in any condition 100% adjustable for pre-travel and post-travel The factory KELTEC trigger stands out in the rimfire market for its crisp feel and light trigger pull. But even good triggers can be made GREAT! The new TANDEMROSS "Victory" Trigger for the KELTEC CP33™, compatible also with the PMR30™ and the CMR30™ is the ultimate KELTEC upgrade - ideal for speed shooting competitors! The TANDEMROSS "Victory" Trigger is pre- and post-travel adjustable to allow each shooter to customize their CP33™, PMR30™ and/or CMR30™ trigger upgrade. The skeletonized, lightweight design of the TANDEMROSS "Victory" trigger provides a flat face that allows the shooter to pull straight back and makes it easier to tell if they are pulling too far to the left or right. In addition to actually reducing the trigger pull weight by up to .5lbs, the flat-faced design also allows the operator to place their finger lower on the trigger, increasing leverage and giving the perception of an even lower pull weight. The textured "Victory" Trigger provides a no-slip surface regardless of speed or weather and allows for short, repeatable, identical trigger pulls. The trigger is made from aircraft-grade aluminum to be lightweight and durable. The TANDEMROSS KELTEC "Victory" Trigger for KELTEC CP33™, CMR30™ and PMR30™ are one of the best KELTEC upgrades for competition shooters. Get yours today and take a giant step closer to VICTORY!



Attributes

- Name: [VICTORY TRIGGER FOR KELTEC PMR/CMR-30 BLACK](#)
- Manufacturer: [TANDEMROSS](#)
- Product no.: 100039458
- Mfr. No.: TK08N0332BLK1
- Finish: Black
- Make: Kel-Tec
- Model: CMR30,CP33,PMR30
- Style: Flat
- Delivery weight: 0.057kg
- Shipping height: 6mm
- Shipping width: 76mm
- Shipping length: 102mm
- UPC: 769498486832

Item details

Made in USA
US export classification: 0A501.c

Table of Contents

- Startpage
- VICTORY Trigger Safety Instruction Guide
- About Us

VICTORY Trigger Safety Instruction Guide

Introduction

Thank you for choosing the VICTORY Trigger for your KELTEC PMR30, CMR30, or CP33. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of your new trigger. Please read this manual carefully before installation and use.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as specified in the product description.
- Always handle firearms with care and follow basic firearm safety rules.
- Keep the trigger and firearm out of reach of children and unauthorized users.
- Regularly inspect the trigger and firearm for any signs of wear or damage before use.
- Store the trigger and firearm in a secure location when not in use.
- Report any unsafe product conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Do not modify the trigger or firearm in any way that is not recommended by the manufacturer.
- Ensure that the firearm is unloaded before installing or adjusting the trigger.
- Always wear appropriate safety gear, including eye protection, when handling firearms.
- Avoid using the trigger in wet or slippery conditions, as this may affect grip and control.
- Be aware of your surroundings and ensure a safe shooting environment when using the firearm.
- If you experience any issues with the trigger, discontinue use and seek assistance.

Instructions for Installation and Usage

Installation Instructions

1. Preparation

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation, such as screwdrivers and wrenches.

2. Remove the Existing Trigger

- Follow the manufacturer's instructions to safely disassemble the firearm.
- Carefully remove the existing trigger from the firearm.

3. Install the VICTORY Trigger

- Align the VICTORY Trigger with the trigger housing.
- Secure the trigger in place using the screws provided in the kit.
- Ensure that the trigger is properly seated and tightened.

4. Adjust the Trigger

- Use the adjustment screws to set the pretravel and posttravel according to your preference.
- Test the trigger pull to ensure it meets your desired specifications.

5. Reassemble the Firearm

- Follow the manufacturer's instructions to reassemble the firearm.
- Ensure that all components are properly secured.

Usage Instructions

- Before each use, conduct a safety check of the firearm and trigger.
- Practice proper grip and stance to ensure control and accuracy.
- Familiarize yourself with the trigger's feel and response during practice sessions.
- Always follow local laws and regulations regarding firearm usage.

Disposal Instructions

- Dispose of the trigger and any associated components in accordance with local regulations.
- If the trigger is damaged or no longer in use, do not throw it in regular trash. Instead, contact local waste management for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding the VICTORY Trigger or safety issues, please refer to the manufacturer's website or customer service for assistance. Ensure you have your product details ready for a more efficient response.

By following these guidelines, you can ensure a safe and enjoyable experience with your VICTORY Trigger. Thank you for your commitment to safety!

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at