

"VICTORY" TRIGGER FOR KELTEC PMR30/CMR30/CP33 - VICTORY TRIGGER FOR KELTEC PMR/CMR-30 RED

[Handgun Parts](#) > [Trigger Group Parts](#) > [Trigger Parts](#) > [Triggers](#)

A a glance: Flat-faced, skeletonized design for better control and feel Textured trigger face offers a no-slip grip in any condition 100% adjustable for pre-travel and post-travel The factory KELTEC trigger stands out in the rimfire market for its crisp feel and light trigger pull. But even good triggers can be made GREAT! The new TANDEMROSS "Victory" Trigger for the KELTEC CP33™, compatible also with the PMR30™ and the CMR30™ is the ultimate KELTEC upgrade - ideal for speed shooting competitors! The TANDEMROSS "Victory" Trigger is pre- and post-travel adjustable to allow each shooter to customize their CP33™, PMR30™ and/or CMR30™ trigger upgrade. The skeletonized, lightweight design of the TANDEMROSS "Victory" trigger provides a flat face that allows the shooter to pull straight back and makes it easier to tell if they are pulling too far to the left or right. In addition to actually reducing the trigger pull weight by up to .5lbs, the flat-faced design also allows the operator to place their finger lower on the trigger, increasing leverage and giving the perception of an even lower pull weight. The textured "Victory" Trigger provides a no-slip surface regardless of speed or weather and allows for short, repeatable, identical trigger pulls. The trigger is made from aircraft-grade aluminum to be lightweight and durable. The TANDEMROSS KELTEC "Victory" Trigger for KELTEC CP33™, CMR30™ and PMR30™ are one of the best KELTEC upgrades for competition shooters. Get yours today and take a giant step closer to VICTORY!



Attributes

- Name: [VICTORY TRIGGER FOR KELTEC PMR/CMR-30 RED](#)
- Manufacturer: [TANDEMROSS](#)
- Product no.: 100039459
- Mfr. No.: TK08N0332RED1
- Finish: Red
- Make: Kel-Tec
- Model: CMR30,CP33,PMR30
- Style: Flat
- Delivery weight: 0.057kg
- Shipping height: 6mm
- Shipping width: 76mm
- Shipping length: 102mm
- UPC: 769498484548

Item details

Made in USA
US export classification: 0A501.c

Table of Contents

- Startpage
- VICTORY Trigger Safety Instructions
- About Us

VICTORY Trigger Safety Instructions

Introduction

Thank you for choosing the VICTORY Trigger for your KELTEC PMR30, CMR30, or CP33. This product is designed to enhance your shooting experience while ensuring safety and compliance with the EU General Product Safety Regulation (GPSR). Please read this safety instruction guide carefully to ensure proper use and maintenance of your trigger.

General Safety Guidelines

- Ensure that the trigger is installed correctly according to the manufacturer's instructions.
- Always handle firearms with care and follow all safety protocols.
- Store the trigger and any associated equipment in a secure location, away from children and unauthorized users.
- Regularly inspect the trigger for signs of wear or damage. If any issues are found, discontinue use immediately and consult a professional.
- Be aware of your surroundings and ensure a safe shooting environment at all times.

Specific Safety Precautions for Use

- Only use the VICTORY Trigger with KELTEC PMR30, CMR30, or CP33 firearms.
- Do not modify the trigger or any part of your firearm beyond the manufacturer's specifications.
- Ensure that the firearm is unloaded before installing or adjusting the trigger.
- Use appropriate eye and ear protection when using firearms.
- Be mindful of trigger pull weight adjustments; excessive adjustments can lead to unintended discharges.
- If you experience any malfunctions while using the trigger, stop using it immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Installation:

- Ensure that the firearm is unloaded.
- Remove the factory trigger according to the KELTEC PMR30, CMR30, or CP33 user manual.
- Install the VICTORY Trigger by following the provided installation instructions.
- Adjust pretravel and posttravel settings as desired, ensuring they are within safe limits.
- Test the trigger function without ammunition to ensure proper installation.

2. Usage:

- Always keep your finger off the trigger until ready to shoot.
- Maintain a proper shooting stance and grip when using the firearm.
- Practice safe shooting habits, including knowing your target and what is beyond it.
- After each use, clean and maintain the trigger and firearm as per the manufacturer's guidelines.

Disposal Instructions

- Dispose of the VICTORY Trigger in accordance with local regulations regarding electronic and metal waste.
- Do not dispose of the trigger in regular household waste.
- Contact local recycling centers or waste disposal facilities for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or concerns regarding the VICTORY Trigger, please consult the manufacturer's website or customer service for assistance.

By following these safety instructions, you can ensure a safe and enjoyable experience with your VICTORY Trigger. Thank you for your attention to safety!

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at