

LOAD-MASTER PROGRESSIVE PRESS SHELL PLATES - LEE PRECISION #21L LOAD-MASTER PROGRESSIVE SHELL PLATE

[Reloading](#) > [Shellholders & Shellplates](#)

Lee quick change shell plates for the Load-Master Press.



Attributes

- Name: [LEE PRECISION #21L LOAD-MASTER PROGRESSIVE SHELL PLATE](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 100040834
- Mfr. No.: 90984
- Cartridge: 6.8mm Special, .224 Valkyrie
- Style: Press Type
- Delivery weight: 0.15kg
- Shipping height: 16mm
- Shipping width: 67mm
- Shipping length: 86mm
- UPC: 734307909840

Item details

Made in USA

Table of Contents

- Startpage
- LOADMASTER PROGRESSIVE PRESS SHELL PLATES SAFETY INSTRUCTIONS
- About Us

LOADMASTER PROGRESSIVE PRESS SHELL PLATES SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the LOADMASTER PROGRESSIVE PRESS SHELL PLATES by Lee Precision. This guide provides essential safety instructions to ensure the safe use of the shell plates with the LoadMaster Press. Please read this document carefully to understand how to operate and maintain the product safely.

General Safety Guidelines

- Ensure that the shell plates are compatible with your LoadMaster Press model before use.
- Always handle the shell plates with clean, dry hands to prevent contamination and ensure proper operation.
- Keep the shell plates out of reach of children and vulnerable individuals to avoid accidents.
- Regularly inspect the shell plates for any signs of damage or wear. Do not use damaged plates.
- Store the shell plates in a cool, dry place away from direct sunlight and extreme temperatures.
- Follow all local laws and regulations regarding the use of reloading equipment and components.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye protection and gloves, when using the LoadMaster Press.
- Ensure that the press is securely mounted and stable before operating.
- Do not exceed the recommended cartridge specifications for the shell plates.
- Avoid using the shell plates for any purpose other than their intended use with the LoadMaster Press.
- Be cautious of sharp edges on the shell plates that may cause injury.
- If you experience any issues during operation, stop using the equipment immediately and consult the user manual.

Instructions for Installation and Usage

1. Installation of Shell Plates:

- Ensure the LoadMaster Press is unplugged and not in operation.
- Remove any existing shell plate from the press by loosening the retaining screws.
- Align the new shell plate with the mounting holes on the press.
- Secure the shell plate in place by tightening the retaining screws until snug. Do not overtighten.

2. Using the Shell Plates:

- Set your LoadMaster Press to the appropriate settings for the cartridge you are loading.
- Insert the appropriate cartridge case into the shell plate.
- Follow the reloading process as outlined in the LoadMaster Press user manual.
- Monitor the operation closely for any irregularities or issues.

3. PostUse Care:

- After use, clean the shell plates with a soft cloth to remove any residue.
- Store the shell plates in their designated storage area to prevent damage.

Disposal Instructions

- Dispose of any damaged or unusable shell plates in accordance with local waste disposal regulations.
- Do not throw shell plates in regular household trash if they are deemed hazardous. Check with local authorities for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the LOADMASTER PROGRESSIVE PRESS SHELL PLATES, please refer to the manufacturer's contact information provided with the product packaging or visit the manufacturer's website.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of your LOADMASTER PROGRESSIVE PRESS SHELL PLATES. Always prioritize safety and consult with professionals if you are unsure about any aspect of the product use. Thank you for your attention to these guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk