

BREECH LOCK RAM PRIME - LEE PRECISION BREECH LOCK RAM PRIME

[Reloading](#) > [Reloading Presses](#) > [Single Stage Presses](#)

Start priming in seconds, nothing to adjust. Includes small and large priming assemblies, no tiny parts to fumble with or lose. Effortless priming in the tightest pockets. Uses any brand press shell holder. Safe with all brands of primers. Works in any Lee Breech Lock press or 1 1/4-12 Breech Lock Update Kit | 1 1/2-12 Breech Lock Update Kit adapter.



Attributes

- Name: [LEE PRECISION BREECH LOCK RAM PRIME](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 100040907
- Mfr. No.: 91612
- Delivery weight: 0.132kg
- Shipping height: 38mm
- Shipping width: 38mm
- Shipping length: 114mm
- UPC: 734307916121

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instructions for BREECH LOCK RAM PRIME
- About Us

Safety Instructions for BREECH LOCK RAM PRIME

Introduction

Thank you for choosing the BREECH LOCK RAM PRIME by LEE PRECISION. This product is designed to make the priming process quick and effortless. However, to ensure your safety and the safe use of this product, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure that you read all instructions and warnings provided with the product.
- Always use the product in accordance with the manufacturer's guidelines.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly check for any updates or recalls related to the product on the EU Safety Gate platform.
- Report any unsafe conditions or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Use only the recommended small and large priming assemblies included with the product.
- Always ensure that the press is securely mounted before use.
- Avoid using the product if it appears damaged or if any components are missing.
- Do not attempt to modify or alter the product in any way.
- Use appropriate personal protective equipment (PPE), such as safety glasses, when operating the press.
- Be aware of your surroundings and maintain a clean workspace to prevent accidents.

Instructions for Installation and Usage

1. Installation:

- Ensure that the press is powered off and unplugged before installation.
- Attach the Breech Lock RAM Prime to your Lee Breech Lock press or the appropriate Breech Lock Update Kit adapter.
- Secure the assembly by following the manufacturer's installation instructions.

2. Usage:

- Load the appropriate priming assembly (small or large) into the Breech Lock RAM Prime.
- Insert the shell holder compatible with your press.
- Place the primer in the designated primer pocket.
- Operate the press according to the manufacturer's instructions, ensuring smooth and controlled movements.
- After use, remove any remaining primers and clean the unit as per the maintenance guidelines.

Disposal Instructions

- Dispose of any used or damaged primers and components in accordance with local regulations.
- Do not dispose of the product in household waste. Follow local environmental guidelines for the disposal of machinery and related components.

Contact Information for Further Support

For any inquiries regarding safety, usage, or support, please consult the manufacturer's website or contact the designated EU contact point associated with this product. Always ensure that you have the product details

ready for a more efficient response.

By following these safety instructions, you can ensure a safe and effective experience with your BREECH LOCK RAM PRIME. Thank you for prioritizing safety in your reloading activities!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk