

AR-15 BOLT GAS RING - BROWNELLS BRN AR-15 BOLT GAS RING, STAINLESS STEEL

[Rifle Parts](#) > [Bolt Parts](#) > [Gas Rings](#)

OEM AR-15/M16 replacement Bolt Gas Ring. Sold as a single ring.



Attributes

- Name: [BROWNELLS BRN AR-15 BOLT GAS RING, STAINLESS STEEL](#)
- Manufacturer: [BROWNELLS](#)
- Product no.: 100040952
- Mfr. No.: AZ-0009
- Weapon type: AR-15
- Delivery weight: 0.005kg
- Shipping height: 3mm
- Shipping width: 76mm
- Shipping length: 152mm
- UPC: 050806029576

Item details

Made in USA

Table of Contents

- Startpage
- AR15 Bolt Gas Ring Safety Instructions
- About Us

AR15 Bolt Gas Ring Safety Instructions

Introduction

Thank you for choosing the AR15 Bolt Gas Ring manufactured by BROWNELLS. This document provides essential safety instructions and guidelines to ensure the safe use and installation of your product. Please read this manual thoroughly before use.

General Safety Guidelines

- Always ensure that the firearm is unloaded before installing or replacing the gas ring.
- Keep the gas ring and all firearm components out of reach of children and unauthorized users.
- Inspect the gas ring regularly for signs of wear or damage. Replace if necessary.
- Do not attempt to modify the gas ring or any firearm components.
- Use only OEM (Original Equipment Manufacturer) parts for replacements to maintain safety and reliability.
- Report any unsafe conditions or product failures to the appropriate authorities.

Specific Safety Precautions for Use

- Ensure that you are familiar with the operation of your AR15/M16 firearm before using this product.
- Always follow the manufacturer's instructions for your firearm regarding the use of gas rings.
- Avoid using the firearm in adverse conditions (e.g., extreme heat, cold, or humidity) that may affect the gas ring's performance.
- Be aware of your surroundings and ensure a safe shooting environment.

Instructions for Installation and Usage

1. Preparation

- Ensure that the firearm is completely unloaded.
- Gather necessary tools, including a cleaning rod or punch for removal of the bolt carrier group.

2. Removing the Old Gas Ring

- Disassemble the bolt carrier group according to the manufacturer's instructions.
- Locate the old gas ring on the bolt. Carefully remove it by sliding it off the bolt.

3. Installing the New Gas Ring

- Take the new AR15 Bolt Gas Ring and ensure it is free from any debris or defects.
- Slide the new gas ring onto the bolt. Ensure it fits snugly in place.
- Reassemble the bolt carrier group following the manufacturer's instructions.

4. Final Inspection

- After installation, perform a visual inspection to ensure the gas ring is correctly installed.
- Test the operation of the firearm in a safe environment before regular use.

Disposal Instructions

- Dispose of any old or damaged gas rings in accordance with local regulations.
- Do not throw the gas ring in regular household waste. Check for recycling options or hazardous waste disposal facilities in your area.

Contact Information for Further Support

For any questions or concerns regarding the installation or use of the AR15 Bolt Gas Ring, please refer to the manufacturer's website or customer service resources.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk