

AR-15 EXTRACTOR SPRING INSERT - BROWNELL'S BRN AR-15 BOLT EXTRACTOR SPRING INSERT, BLACK

[Home](#)

OEM AR-15/M16 replacement Extractor Spring Insert.



Attributes

- Name: [BROWNELL'S BRN AR-15 BOLT EXTRACTOR SPRING INSERT, BLACK](#)
- Manufacturer: [BROWNELL'S](#)
- Product no.: 100040956
- Mfr. No.: AZ-0019
- Weapon type: AR-15
- Delivery weight: 0.005kg
- Shipping height: 3mm
- Shipping width: 76mm
- Shipping length: 152mm
- UPC: 050806029613

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for AR15 Extractor Spring Insert
- About Us

Safety Instruction Guide for AR15 Extractor Spring Insert

Introduction

Thank you for choosing the AR15 Extractor Spring Insert by Brownells. This product is designed to enhance the performance of your AR15/M16 rifle. To ensure safe and effective use, please read this safety instruction guide carefully. It contains essential information regarding product safety, installation, and usage.

General Safety Guidelines

- Ensure that you understand the operation of your firearm before installing or using the Extractor Spring Insert.
- Always treat firearms as if they are loaded.
- Store all firearm components, including the Extractor Spring Insert, out of reach of children and unauthorized users.
- Regularly inspect your firearm and its components for any signs of wear or damage.
- Use only compatible parts and accessories with your AR15/M16 rifle.
- Follow all local laws and regulations regarding firearm ownership and usage.

Specific Safety Precautions for Use

- Do not attempt to modify or alter the Extractor Spring Insert in any way.
- Ensure that the firearm is unloaded before beginning installation.
- Wear safety glasses to protect your eyes from potential debris during installation.
- Avoid using the Extractor Spring Insert in firearms that it is not designed for.
- If you experience any issues with the Extractor Spring Insert, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools, including a punch tool and a hammer.
- Ensure you are in a safe and secure environment to perform the installation.

2. Installation Steps:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Remove the bolt carrier group from the firearm.
- Locate the existing Extractor Spring Insert in the bolt.
- Use the punch tool to carefully remove the old Extractor Spring Insert.
- Place the new Extractor Spring Insert into the bolt, ensuring it is seated properly.
- Reassemble the bolt carrier group and reinsert it into the firearm.

3. PostInstallation:

- Conduct a function check to ensure the firearm operates correctly.
- Store the firearm in a secure location when not in use.

Disposal Instructions

- Dispose of any old or damaged components in accordance with local regulations.
- Do not dispose of firearm parts in regular household waste.
- Contact local waste management authorities for guidance on proper disposal methods.

Contact Information for Further Support

For safety inquiries or further assistance, please reach out to your local firearms dealer or a qualified gunsmith. They can provide you with the necessary support and information regarding your product.

Conclusion

By following these safety instructions, you can ensure the safe use of the AR15 Extractor Spring Insert. Always remain vigilant and prioritize safety when handling firearms. Thank you for your attention to these important guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk