

# SLIDE ADAPTER PLATE FOR GLOCK® GEN 3/4 - STRIKE INDUSTRIES

## SLIDE ADAPTER PLATE STEEL BLACK

[Handgun Parts](#) > [Slide Parts](#) > [Slide Hardware](#) > [Slide Inserts](#)

The Strike Industries Slide Adapter Plate (SAP) allows you to use a GEN3 slide, in conjunction with a Strike Industries Mass Driver Comp, on a GEN4 frame.

Naturally a GLOCK® factory or aftermarket GEN3 slide will fit and function on a GEN4 frame, but there are a few issues to address. First is the ugly gap and the second is the flex in the frame because of the large hole. Install the SAP in seconds and prevent any movement of the GEN3 recoil rod and spring from possibly damaging your GLOCK® GEN4. Because there is an abundance of aftermarket GEN3 slide options, Strike Industries wants to make sure you are not restricted by fitment and have your choice to fully customize your pistol. Giving you a cost-effective resolution with SI design, the Strike Industries Slide Adapter Plate won't hold you back on form and function. Adapt GEN3 slide to GEN4 frame Prevent flex in frame Eliminate the gap Lightweight



### Attributes

- Name: [STRIKE INDUSTRIES SLIDE ADAPTER PLATE STEEL BLACK](#)
- Manufacturer: [STRIKE INDUSTRIES](#)
- Product no.: 100043588
- Mfr. No.: SI-G-SAP-MDC
- Model: Gen 4,Gen 3
- Weapon type: Glock
- Delivery weight: 0.136kg
- Shipping height: 13mm
- Shipping width: 114mm
- Shipping length: 152mm
- UPC: 793811763973

### Item details

US export classification: 0A501.x

# Table of Contents

- Startpage
- Safety Instruction Guide for Strike Industries Slide Adapter Plate for GLOCK® Gen 3/4
- About Us

# Safety Instruction Guide for Strike Industries Slide Adapter Plate for GLOCK® Gen 3/4

## Introduction

Thank you for choosing the Strike Industries Slide Adapter Plate (SAP) for your GLOCK® Gen 3/4. This guide provides essential safety information, installation instructions, and usage precautions to ensure your safety and the optimal performance of your product. Please read this guide carefully before using the Slide Adapter Plate.

## General Safety Guidelines

- Ensure that the Slide Adapter Plate is compatible with your specific model of GLOCK® before installation.
- Always handle firearms safely and responsibly. Follow all local laws and regulations regarding firearm usage.
- Regularly inspect the Slide Adapter Plate for any signs of wear or damage before each use.
- Store the Slide Adapter Plate in a secure location, away from children and unauthorized users.
- In case of any unusual performance or damage, cease use immediately and consult a qualified firearms technician.

## Specific Safety Precautions for Use

- **Compatibility Check:** Confirm that your GLOCK® is a Gen 4 frame and that you are using a Gen 3 slide. The Slide Adapter Plate is designed specifically for this combination.
- **Installation Environment:** Perform the installation in a clean, dry, and welllit environment to avoid any potential hazards.
- **Tools:** Use appropriate tools for installation. Avoid using excessive force that may damage the Slide Adapter Plate or your firearm.
- **Flex and Gap Prevention:** The Slide Adapter Plate is designed to prevent flex in the frame and eliminate gaps. Ensure it is installed correctly to maintain firearm integrity.
- **Recoil Rod and Spring:** Ensure that the GEN3 recoil rod and spring are properly seated in the adapter to prevent any movement that could cause damage.

## Instructions for Installation and Usage

1. **Prepare Your Firearm:** Ensure that your GLOCK® is unloaded and pointed in a safe direction.
2. **Remove Existing Slide:** Carefully remove the existing slide from your GLOCK® Gen 4 frame.
3. **Install the Slide Adapter Plate:**
  - Align the Slide Adapter Plate with the mounting points on the frame.
  - Press down firmly until the plate is securely seated.
4. **Attach the GEN3 Slide:**
  - Align the GEN3 slide with the Slide Adapter Plate.
  - Slide it into place until it locks securely.
5. **Check Installation:**
  - Inspect the installation to ensure there are no gaps or misalignments.
  - Test the movement of the slide to ensure it operates smoothly.
6. **Final Inspection:**
  - Doublecheck that all components are secure and functioning properly before use.

## Disposal Instructions

- Dispose of the Slide Adapter Plate responsibly. Follow local regulations for disposal of firearm accessories.
- If the Slide Adapter Plate is damaged or no longer in use, consider recycling it if possible.

## **Contact Information for Further Support**

For any questions or concerns regarding the Slide Adapter Plate, please consult the manufacturer's website or contact their customer support for assistance. Always ensure that you are following the latest safety guidelines and product updates.

Please remember that your safety is paramount. By following these guidelines, you can ensure a safe and enjoyable experience with your Strike Industries Slide Adapter Plate.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)