

SPORTSMEN'S RANGE BAG - UNCLE MIKES SPORTSMEN'S RANGE BAG BLACK

[Shooting Accessories](#) > [Range Gear](#) > [Range Bags](#)

The Sportsmen's Range Bag from Uncle Mike's is ideal for carrying two handguns, ammo, and range supplies.



Attributes

- Name: [UNCLE MIKES SPORTSMEN'S RANGE BAG BLACK](#)
- Manufacturer: [UNCLE MIKES](#)
- Product no.: 100043817
- Mfr. No.: 53500BK
- Colour: Black
- Style: Range Bag
- Delivery weight: 1.102kg
- Shipping height: 102mm
- Shipping width: 229mm
- Shipping length: 381mm
- UPC: 043699012794

Table of Contents

- [Startpage](#)
- [Sportsmen's Range Bag Safety Instruction Guide](#)
- [About Us](#)

Sportsmen's Range Bag Safety Instruction Guide

Introduction

Thank you for choosing the Sportsmen's Range Bag from Uncle Mike's. This guide provides essential safety instructions to ensure the safe use of your range bag. Please read and follow these guidelines carefully to maximize your safety and the longevity of the product.

General Safety Guidelines

- Always inspect the bag before use for any signs of damage or wear.
- Keep the bag away from extreme temperatures, moisture, and direct sunlight to prevent material degradation.
- Ensure that the bag is used only for its intended purpose of carrying handguns, ammunition, and range supplies.
- Be aware of your surroundings when using the bag, especially in crowded or public spaces.
- Report any unsafe conditions or incidents related to the bag to the appropriate authorities.

Specific Safety Precautions for Use

- Do not overload the bag beyond its intended capacity, as this may compromise its structural integrity.
- Ensure that all firearms are unloaded before placing them in the bag.
- Keep ammunition securely stored in designated compartments to prevent accidental discharge.
- Avoid placing sharp objects or heavy items that could puncture or damage the bag.
- Store the bag out of reach of children and unauthorized users to prevent accidents.

Instructions for Installation and Usage

• Loading the Bag:

- Open the main compartment and ensure all zippers and fasteners are functioning properly.
- Place handguns in designated padded compartments to prevent movement and damage.
- Store ammunition in the designated side pockets or compartments, ensuring they are securely closed.
- Utilize additional pockets for range supplies such as ear protection, safety glasses, and cleaning kits.

• Carrying the Bag:

- Use the padded shoulder strap or handle for comfortable carrying.
- Adjust the strap length to suit your height and carrying preference.
- When carrying, maintain a firm grip on the bag to prevent dropping or losing control.

• Cleaning and Maintenance:

- Regularly clean the exterior of the bag with a damp cloth to remove dirt and debris.
- For stubborn stains, use mild soap and water. Avoid harsh chemicals that may damage the material.
- Allow the bag to air dry completely before storing it to prevent mold and mildew.

Disposal Instructions

- Dispose of the bag responsibly when it reaches the end of its life cycle.
- If the bag is damaged beyond repair, consider recycling the materials where possible.

- Follow local regulations regarding the disposal of textile products.

Contact Information for Further Support

For any safety inquiries or further assistance regarding your Sportsmen's Range Bag, please refer to the contact information provided on the product packaging or visit the manufacturer's website.

Thank you for your attention to these safety guidelines. Enjoy your time at the range with the Sportsmen's Range Bag!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk