

AR-15 DISCONNECTOR - SONS OF LIBERTY GUN WORKS DISCONNECTOR FOR AR-15

[Rifle Parts](#) > [Triggers Parts](#) > [Disconnecter Parts](#) > [Disconnectors](#)

Sons of Liberty Gun Works factory OEM Disconnector for Mil-Spec AR-15s.



Attributes

- Name: [SONS OF LIBERTY GUN WORKS DISCONNECTOR FOR AR-15](#)
- Manufacturer: [SONS OF LIBERTY GUN WORKS](#)
- Product no.: 100045025
- Mfr. No.: DISCONNECTOR
- Weapon type: AR-15
- Delivery weight: 0.454kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 25mm
- UPC: 785939517613

Item details

Made in USA

US export classification: 0A501.c

Table of Contents

- Startpage
- Safety Instruction Guide for AR15 Disconnector
- About Us

Safety Instruction Guide for AR15 Disconnector

Introduction

Thank you for choosing the AR15 Disconnector from Sons of Liberty Gun Works. This guide provides important safety instructions and guidelines to ensure the safe and proper use of your disconnector. Please read this manual carefully before installation and use.

General Safety Guidelines

- Always treat your firearm as if it is loaded.
- Ensure you are in a safe environment when handling the disconnector.
- Store the disconnector and all firearm components in a secure location, out of reach of children and unauthorized users.
- Be aware of your surroundings when using your firearm and its components.
- Regularly inspect all firearm components for wear and damage.
- Follow all local, state, and federal laws regarding firearm ownership and use.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure that the firearm is completely unloaded before installing or replacing the disconnector.
- Use only OEM parts and accessories to maintain the integrity and safety of your firearm.
- Follow the manufacturer's instructions for installation and usage to prevent malfunctions.
- Do not modify the disconnector or any other firearm components.
- If you experience any issues with your firearm after installation, consult a qualified gunsmith immediately.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools, including a punch tool and a hammer.
- Ensure you are working in a clean, welllit area.

2. Disassembly of Firearm:

- Unload the firearm and ensure it is safe.
- Remove the upper receiver from the lower receiver.
- Take out the trigger assembly from the lower receiver.

3. Installation of Disconnector:

- Locate the disconnector slot in the trigger assembly.
- Insert the disconnector into the slot, ensuring it is seated properly.
- Use the punch tool to secure the disconnector in place as per the manufacturer's specifications.

4. Reassembly of Firearm:

- Reinstall the trigger assembly into the lower receiver.
- Reattach the upper receiver to the lower receiver.
- Perform a function check to ensure proper operation.

5. Usage:

- Always follow standard firearm safety practices when using your AR15.
- Be aware of the disconnector's function and ensure it operates correctly during usage.

Disposal Instructions

- Dispose of any unused or broken components in accordance with local regulations.
- Do not dispose of firearm components in regular trash.
- Contact local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the AR15 Disconnector, please reach out to the manufacturer or a qualified professional. Always ensure you have the latest information and support for your product.

Thank you for prioritizing safety and responsible handling of your firearm components. Your adherence to these guidelines is essential for ensuring a safe and enjoyable experience.

