

AR-15 FIRING PIN - SONS OF LIBERTY GUN WORKS FIRING PIN FOR AR-15

[Rifle Parts](#) > [Bolt Parts](#) > [Firing Pin Parts](#) > [Firing Pins](#)

Sons of Liberty Gun Works factory OEM Firing Pin for Mil-Spec AR-15s.



Attributes

- Name: [SONS OF LIBERTY GUN WORKS FIRING PIN FOR AR-15](#)
- Manufacturer: [SONS OF LIBERTY GUN WORKS](#)
- Product no.: 100045054
- Mfr. No.: M4FIRINGPIN
- Weapon type: AR-15
- Delivery weight: 0.227kg
- Shipping height: 13mm
- Shipping width: 76mm
- Shipping length: 127mm
- UPC: 785939517910

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [AR15 Firing Pin Safety Instructions](#)
- [About Us](#)

AR15 Firing Pin Safety Instructions

Introduction

Thank you for choosing the Sons of Liberty Gun Works Firing Pin for your AR15. This product is designed to provide reliable performance and safety when used correctly. Please read this safety instruction guide thoroughly before installation and use to ensure safe handling and operation.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Ensure that you are familiar with the operation of your AR15 and the specific components being replaced or installed.
- Keep all firearms out of reach of children and unauthorized users.
- Use this product only in accordance with the manufacturer's instructions and guidelines.
- Regularly inspect your firearm and its components for wear and damage.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Do not use the firing pin if it shows signs of wear or damage.
- Ensure that the firearm is unloaded before attempting to install or replace the firing pin.
- Always wear appropriate eye and ear protection when handling firearms.
- Avoid using this product in adverse conditions, such as extreme temperatures or moisture, which can affect performance.
- Ensure that all tools used during installation are in good condition and appropriate for the task.

Instructions for Installation and Usage

1. Preparation:

- Ensure that the AR15 is completely unloaded. Check the chamber and magazine.
- Gather necessary tools, including a punch tool and a hammer.

2. Installation:

- Remove the upper receiver from the lower receiver of the AR15.
- Locate the bolt carrier group and remove it from the upper receiver.
- Using a punch tool, carefully drive out the existing firing pin from the bolt carrier group.
- Insert the new Sons of Liberty Gun Works firing pin into the bolt carrier group.
- Ensure that the firing pin is seated properly and secured in place.
- Reassemble the bolt carrier group and reattach it to the upper receiver.
- Reattach the upper receiver to the lower receiver.

3. Usage:

- After installation, conduct a function check to ensure that the firing pin operates correctly.
- Always keep the firearm pointed in a safe direction during operation.
- Follow all standard safety protocols when firing the weapon.

Disposal Instructions

- Dispose of any old or damaged firing pins in accordance with local regulations.
- Do not dispose of firearms or firearm components in regular household waste.

- Contact local authorities or waste management services for guidance on safe disposal methods.

Contact Information for Further Support

For any inquiries regarding safety, installation, or product performance, please refer to the manufacturer's contact information provided with your product packaging or visit the manufacturer's website for more details.

By following these safety instructions, you can help ensure a safe and enjoyable experience with your AR15. Thank you for your attention to safety and responsible firearm ownership.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk