

# AR-15 FRONT SIGHT SPRING - SONS OF LIBERTY GUN WORKS FRONT SIGHT SPRING FOR AR-15

[Rifle Parts](#) > [Sights](#) > [Sight Parts](#) > [Front Sight Springs](#)

Sons of Liberty Gun Works factory OEM Front Sight Spring for Mil-Spec AR-15s.



## Attributes

- Name: [SONS OF LIBERTY GUN WORKS FRONT SIGHT SPRING FOR AR-15](#)
- Manufacturer: [SONS OF LIBERTY GUN WORKS](#)
- Product no.: 100045061
- Mfr. No.: FRONTSIGHTSPRIN
- Weapon type: AR-15
- Delivery weight: 0.005kg
- Shipping height: 3mm
- Shipping width: 3mm
- Shipping length: 19mm
- UPC: 785939517989

## Item details

Made in USA

# Table of Contents

- Startpage
- AR15 Front Sight Spring Safety Instruction Guide
- About Us

# AR15 Front Sight Spring Safety Instruction Guide

## Introduction

Thank you for choosing the AR15 Front Sight Spring from Sons of Liberty Gun Works. This product is designed to enhance the performance of your MilSpec AR15. To ensure safe and effective use, please read and follow these safety instructions carefully.

## General Safety Guidelines

- Always handle firearms with caution and respect.
- Ensure that the firearm is unloaded before performing any maintenance or installation tasks.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the product for wear or damage before use.
- Follow all local laws and regulations concerning firearm accessories and modifications.

## Specific Safety Precautions for Use

- **Potential Hazards:** Improper installation or use of the front sight spring may lead to malfunction or injury.
- **Avoiding Hazards:**
  - Ensure that the spring is correctly seated in the sight assembly.
  - Do not modify the spring or use it in a manner not intended by the manufacturer.
  - Only use the spring with compatible MilSpec AR15 models.
- **Age Warning:** This product is intended for use by individuals aged 18 and older. Ensure that younger individuals are supervised when handling firearms.

## Instructions for Installation and Usage

### 1. Tools Required:

- Flathead screwdriver
- Punch tool (if necessary)

### 2. Installation Steps:

- Make sure the firearm is unloaded and pointed in a safe direction.
- Remove the existing front sight assembly if applicable.
- Insert the new front sight spring into the designated slot of the front sight assembly.
- Ensure that the spring is seated properly and securely.
- Reattach the front sight assembly to the firearm, ensuring all components are tightened to manufacturer specifications.

### 3. Usage Tips:

- Regularly check the front sight assembly for stability and functionality.
- If you experience any issues such as misalignment or failure to hold zero, inspect the spring and sight assembly for proper installation.

## Disposal Instructions

- Dispose of the product in accordance with local regulations for firearm accessories.
- Do not dispose of the spring in regular household waste. Contact local waste management authorities for proper disposal methods.

## **Contact Information for Further Support**

For questions or concerns regarding the AR15 Front Sight Spring, please reach out to your local retailer or the manufacturer directly. Ensure you have the product details on hand for accurate assistance.

By following these guidelines and instructions, you can ensure the safe and effective use of the AR15 Front Sight Spring. Thank you for prioritizing safety and compliance with the EU General Product Safety Regulation.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)