

EDGE~~BAG~~ GATER - EDGEWOOD SHOOTING BAGS EDGE~~BAG~~ GATER STD 3-1/2"H 3/8" SPREAD 3M SLICK

[Shooting Accessories](#) > [Shooting Rests](#) > [Bench Rest Bags](#)

This is a long, heavy bag - about twice the length of the Original (6" x 13"") - the ultimate in stability. Filled weight can easily top 25 lbs. depending on body height. It features a padded top for resting the trigger hand and includes the same choices of ear combination as the Original. The Gater has a multi-layered all flat base. EDGE model includes the following upgrades: Extra rigid, super flat bag base made with a unique material resists deformation over time "Overlay Ears" - Whether you choose slick material or cordura, a durable layer of leather is added underneath the material which contributes to consistency in shape and performance as well as extreme longevity and resistance to wear. Flatter ear space means the riding surface at the base of the ears has been redesigned to practically eliminate inconsistencies in the transition between the riding surface and the ear base. This remedies any potential drag or grabbing and increases longevity by removing an inherent wear point. Reinforced ear base isolates the ear set from the shape of the bag, contributing to consistency in the contact surface and ear spread. Embroidered cordura tops showcase our brand new logo and highlight the evolution of our designs.

NO IMAGE
AVAILABLE

Attributes

- Name: [EDGEWOOD SHOOTING BAGS EDGE~~BAG~~ GATER STD 3-1/2"H 3/8" SPREAD 3M SLICK](#)
- Manufacturer: [EDGEWOOD SHOOTING BAGS](#)
- Product no.: 100045559
- Mfr. No.: EDGE STD GATER
- Colour: Black/ Tan
- Material: 3M Slick,Leather
- Style: Rabbit,Rear Bag
- Delivery weight: 0.635kg
- Shipping height: 102mm
- Shipping width: 178mm
- Shipping length: 330mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for EDGEBA^G GATER EDGEWOOD SHOOTING BAGS
- About Us

Safety Instruction Guide for EDGEBA~~G~~ GATER EDGEWOOD SHOOTING BAGS

Introduction

Thank you for choosing the EDGEBA~~G~~ GATER EDGEWOOD SHOOTING BAG. This guide provides important safety information and instructions to ensure the safe use of this product. Please read this guide carefully before using the bag to understand how to use it safely and effectively.

General Safety Guidelines

- **Product Safety:** This product is designed to ensure safe use during shooting activities. Always follow the instructions provided to minimize risks.
- **Enhanced Recalls:** In the event of a safety issue, recall notices will be standardized, and remedies will be provided at no cost for dangerous products.
- **Online Shopping Safety:** Online purchases of this product are subject to the same safety protections as those made in physical stores. Ensure you buy from authorized retailers.
- **Special Consumer Focus:** Extra safeguards are in place for vulnerable groups, including children. Keep this product out of reach of children.
- **EU Contact Point:** For safety inquiries, please refer to the relevant EU contact point associated with this product.
- **Rapid Alerts:** Stay informed about product safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Weight Awareness:** The filled weight of the bag can exceed 25 lbs. Ensure you are physically capable of handling the bag safely.
- **Proper Handling:** Always lift the bag using proper lifting techniques to avoid injury.
- **Surface Stability:** Ensure the bag is placed on a stable surface to prevent accidental tipping or rolling.
- **Ear Space Caution:** The redesigned ear space minimizes inconsistencies. However, ensure that the bag is used on compatible surfaces to avoid damage.
- **Usage with Firearms:** Always follow firearm safety rules when using this bag in conjunction with shooting activities. Ensure that firearms are handled responsibly.

Instructions for Installation and Usage

• Setting Up the Bag:

- Place the bag on a flat, stable surface.
- Ensure that the padded top is facing upwards for comfortable use.

• Using the Bag:

- Rest your trigger hand on the padded top for stability.
- Adjust your shooting position to maintain balance and control.
- Ensure that the bag is not obstructing your line of sight or shooting area.

• Care and Maintenance:

- Regularly check the bag for any signs of wear or damage.
- Clean the bag with a damp cloth; avoid using harsh chemicals that may damage the material.
- Store the bag in a dry place when not in use to prevent moisture damage.

Disposal Instructions

- **Responsible Disposal:** When disposing of this product, follow local regulations regarding waste disposal.
- **Material Recycling:** Check if the materials can be recycled. Leather and synthetic materials may have specific disposal requirements.
- **Environmental Considerations:** Dispose of the bag in a way that minimizes environmental impact. Avoid leaving it in public spaces or natural environments.

Contact Information for Further Support

For additional support or inquiries regarding the safety and use of the EDGEBAK GATER EDGEWOOD SHOOTING BAG, please refer to the authorized retailer or the product's EU contact point.

Thank you for prioritizing safety while using the EDGEBAK GATER EDGEWOOD SHOOTING BAG. Your adherence to these guidelines helps ensure a safe and enjoyable experience.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk