

EDGEBUG GATER - EDGEWOOD SHOOTING BAGS EDGEBUG GATER TALL 4"H 3/4" SPREAD 3M SLICK

[Shooting Accessories](#) > [Shooting Rests](#) > [Bench Rest Bags](#)

This is a long, heavy bag - about twice the length of the Original (6" x 13"") - the ultimate in stability. Filled weight can easily top 25 lbs. depending on body height. It features a padded top for resting the trigger hand and includes the same choices of ear combination as the Original. The Gater has a multi-layered all flat base. EDGE model includes the following upgrades: Extra rigid, super flat bag base made with a unique material resists deformation over time "Overlay Ears" - Whether you choose slick material or cordura, a durable layer of leather is added underneath the material which contributes to consistency in shape and performance as well as extreme longevity and resistance to wear. Flatter ear space means the riding surface at the base of the ears has been redesigned to practically eliminate inconsistencies in the transition between the riding surface and the ear base. This remedies any potential drag or grabbing and increases longevity by removing an inherent wear point. Reinforced ear base isolates the ear set from the shape of the bag, contributing to consistency in the contact surface and ear spread. Embroidered cordura tops showcase our brand new logo and highlight the evolution of our designs.

NO IMAGE
AVAILABLE

Attributes

- Name: [EDGEWOOD SHOOTING BAGS EDGEBUG GATER TALL 4"H 3/4" SPREAD 3M SLICK](#)
- Manufacturer: [EDGEWOOD SHOOTING BAGS](#)
- Product no.: 100045565
- Mfr. No.: EDGE TALL GATER
- Colour: Black/ Tan
- Material: 3M Slick,Leather
- Style: Rear Bag,Rabbit
- Delivery weight: 0.635kg
- Shipping height: 102mm
- Shipping width: 178mm
- Shipping length: 330mm

Item details

Made in USA

Table of Contents

- Startpage
- EDGEBAK GATER EDGEWOOD SHOOTING BAGS Safety Instruction Guide
- About Us

EDGEBA^G GATER EDGEWOOD SHOOTING BAGS

Safety Instruction Guide

Introduction

Thank you for choosing the EDGEBA^G GATER EDGEWOOD SHOOTING BAGS. This guide provides important safety information and instructions to ensure safe and effective use of your shooting bag. Please read this guide thoroughly before using the product.

General Safety Guidelines

- **Product Safety:** Ensure the safe use of the shooting bag by following all instructions provided in this manual. The bag is designed for stability and performance but may pose risks if misused.
- **Enhanced Recalls:** In the event of a recall, stay informed through standardized notices. If you receive a recall notice, follow the instructions provided to return or remedy the product.
- **Online Shopping:** If purchased online, ensure that the seller meets all safety requirements. You have the same protections as if you purchased from a physical store.
- **Special Consumer Focus:** Extra care should be taken when using this product around vulnerable groups, especially children. Ensure they are supervised at all times during use.
- **EU Contact Point:** For any safety inquiries, please refer to the product packaging or the retailer for an EU-based contact.
- **Rapid Alerts:** Stay updated on product safety through the EU's Safety Gate platform. Regularly check for any alerts regarding the EDGEBA^G GATER.

Specific Safety Precautions for Use

- **Weight Handling:** The filled weight of the bag can exceed 25 lbs. Ensure that you are capable of lifting and handling this weight safely to avoid injury.
- **Surface Stability:** Always place the shooting bag on a stable surface to prevent slipping or tipping during use.
- **Proper Use:** Use the shooting bag only for its intended purpose. Do not use it for any other activities that could lead to injury.
- **Check for Damage:** Regularly inspect the bag for any signs of wear or damage. Do not use the bag if it shows significant wear or structural integrity issues.
- **Ear Space:** Be aware of the redesigned flatter ear space, which is intended to enhance performance. Ensure that your setup accommodates this design to avoid any potential drag or grabbing.

Instructions for Installation and Usage

• Setting Up the Bag:

1. Place the shooting bag on a flat, stable surface.
2. Ensure that the padded top is facing upwards for optimal comfort when resting your trigger hand.

• Filling the Bag:

1. If the bag is not pre-filled, fill it according to the manufacturer's recommendations. Ensure that the filling does not exceed the recommended capacity.
2. Securely close any openings to prevent spillage during use.

• Using the Bag:

1. Position the bag in your desired location for shooting.

2. Rest your trigger hand on the padded top for stability.
3. Ensure that the ear base is properly aligned with your shooting setup to maintain consistency and performance.

- **PostUse Care:**

1. After use, clean the bag according to the care instructions provided by the manufacturer.
2. Store the bag in a dry place to prevent mold or degradation of materials.

Disposal Instructions

- **General Disposal:** Dispose of the bag in accordance with local regulations. Check if the materials can be recycled or if they require special disposal methods.
- **Environmental Considerations:** Do not dispose of the bag in a manner that could harm the environment. Always follow local waste disposal guidelines.

Contact Information for Further Support

For any questions regarding safety or product usage, please refer to the product packaging or contact your retailer for further assistance. Your safety and satisfaction are our top priorities.

Thank you for using the EDGEBA^G GATER EDGEWOOD SHOOTING BAGS. By following these safety instructions, you can ensure a safe and enjoyable experience with your shooting bag.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk