

EDGEWOOD SHOOTING BAGS EDGEBAG NEW FARLEY FRONT REST 3" VARMINT 3M SLICK

[Shooting Accessories](#) > [Shooting Rests](#) > [Bench Rest Bags](#)

Front bag for the ""New Farley"" tops. These are the new style Farley tops that are machined from one solid piece of aluminum. If your Farley top is constructed using hinged side-plates, please order the ""Old Farley"" front bag. Base measures 5-1/8" X 1-3/4". EDGE model includes extra tall ears to guide and capture the stock more securely.

NO IMAGE
AVAILABLE

Attributes

- Name: [EDGEWOOD SHOOTING BAGS EDGEBAG NEW FARLEY FRONT REST 3" VARMINT 3M SLICK](#)
- Manufacturer: [EDGEWOOD SHOOTING BAGS](#)
- Product no.: 100045603
- Mfr. No.: EDGE NEW FARLEY
- Colour: Black/ Tan
- Material: Leather,3M Slick
- Style: Rest Top,Front Bag
- Delivery weight: 0.091kg
- Shipping height: 102mm
- Shipping width: 102mm
- Shipping length: 178mm

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for EDGEBAG NEW FARLEY FRONT REST](#)
- [About Us](#)

Safety Instruction Guide for EDGE BAG NEW FARLEY FRONT REST

Introduction

Thank you for choosing the EDGE BAG NEW FARLEY FRONT REST. This guide provides essential safety instructions to ensure the safe and effective use of your shooting bag. Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure that the product is used in accordance with the manufacturer's instructions.
- Always inspect the product for any signs of wear or damage before use.
- Keep the product out of reach of children and vulnerable individuals to prevent accidents.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform regularly.

Specific Safety Precautions for Use

- Use the bag only for its intended purpose as a front rest for shooting.
- Do not exceed the weight limit suggested by the manufacturer.
- Ensure that the shooting area is clear of obstructions and that you have a safe backdrop.
- Always maintain a safe distance from others when using the shooting bag.
- Avoid using the product in wet or slippery conditions to prevent accidents.

Instructions for Installation and Usage

1. Setting Up the Shooting Bag:

- Place the front rest on a stable surface.
- Ensure that the base of the bag is positioned securely to avoid tipping.

2. Using the Front Rest:

- Position the stock of your firearm securely in the extra tall ears of the bag.
- Adjust the position of the bag as needed to ensure proper alignment with your target.
- Confirm that the firearm is stable and secure before taking aim.

3. PostUse Care:

- After use, remove any debris or dirt from the bag.
- Store the product in a dry place to maintain its condition and longevity.

Disposal Instructions

- When the product has reached the end of its life, dispose of it responsibly.
- Follow local regulations for the disposal of materials such as leather and synthetic materials.
- Do not dispose of the product in regular household waste if it contains hazardous materials.

Contact Information for Further Support

For any questions or concerns regarding the safety and use of the EDGE BAG NEW FARLEY FRONT REST, please refer to the manufacturer's contact details included with the product packaging.

Thank you for your attention to these safety instructions. Your safety is our priority.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk