

EDGE~~BAG~~ NEW FARLEY FRONT REST - EDGEWOOD SHOOTING BAGS EDGE~~BAG~~ NEW FARLEY FRONT REST 2-1/4" HUNTER BLACK CORDURA

[Shooting Accessories](#) > [Shooting Rests](#) > [Bench Rest Bags](#)

Front bag for the ""New Farley"" tops. These are the new style Farley tops that are machined from one solid piece of aluminum. If your Farley top is constructed using hinged side-plates, please order the ""Old Farley"" front bag. Base measures 5-1/8" X 1-3/4". EDGE model includes extra tall ears to guide and capture the stock more securely.

NO IMAGE
AVAILABLE

Attributes

- Name: [EDGEWOOD SHOOTING BAGS EDGE~~BAG~~ NEW FARLEY FRONT REST 2-1/4" HUNTER BLACK CORDURA](#)
- Manufacturer: [EDGEWOOD SHOOTING BAGS](#)
- Product no.: 100045604
- Mfr. No.: EDGE NEW FARLEY
- Colour: Black/ Tan
- Material: Cordura,Leather
- Style: Front Bag,Rest Top
- Delivery weight: 0.091kg
- Shipping height: 102mm
- Shipping width: 102mm
- Shipping length: 178mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for EDGEBAK NEW FARLEY FRONT REST
- About Us

Safety Instruction Guide for EDGEBA^G NEW FARLEY FRONT REST

Introduction

Thank you for choosing the EDGEBA^G NEW FARLEY FRONT REST. This guide provides important safety instructions and guidelines to ensure the safe use of your product. Please read this document carefully before using the shooting bag to maximize safety and performance.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as a front bag for the "New Farley" tops.
- Inspect the product for any visible damage or defects before each use. Do not use if damaged.
- Keep the product out of reach of children and vulnerable individuals to prevent accidents.
- Always use the product in a safe and controlled environment, away from unauthorized individuals.
- Follow all local laws and regulations regarding the use of shooting equipment.

Specific Safety Precautions for Use

- Use the front bag on a stable and level surface to prevent tipping or slipping.
- Ensure that the stock of your firearm is securely captured by the extra tall ears of the bag to enhance stability.
- Avoid overloading the bag beyond its intended capacity, as this may compromise its stability and safety.
- Do not place any part of your body in front of the firearm while in use.
- Always treat firearms as if they are loaded. Keep the muzzle pointed in a safe direction at all times.

Instructions for Installation and Usage

1. Preparation:

- Remove the front bag from its packaging.
- Inspect the bag for any signs of damage or defects.

2. Placement:

- Place the front bag on a stable shooting platform or bench.
- Ensure that the surface is flat and secure.

3. Using the Bag:

- Position the firearm on the front bag, ensuring that the stock is aligned with the extra tall ears.
- Adjust the position of the firearm as necessary to achieve a comfortable shooting stance.
- Confirm that the firearm is secure and stable before taking any shots.

4. PostUse:

- After use, safely store the front bag in a dry place away from direct sunlight and moisture.
- Regularly check the bag for wear and tear, and replace it if necessary.

Disposal Instructions

- Dispose of the product in accordance with local regulations for waste disposal.
- If the product is no longer usable, consider recycling any materials that can be recycled, such as fabric or

metal components.

Contact Information for Further Support

For any inquiries regarding safety or product performance, please refer to the manufacturer's contact information provided on the packaging or product documentation.

By following these safety instructions and guidelines, you can ensure a safe and enjoyable experience with your EDGEBAK NEW FARLEY FRONT REST. Thank you for your attention to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk