

EDGEWOOD FRONT BENCHREST BAGS - EDGEWOOD SHOOTING BAGS STANDARD FRONT REST 2-1/4" HUNTER W/REINFORCED TOP SLICK

[Shooting Accessories](#) > [Shooting Rests](#) > [Bench Rest Bags](#)

Edgewood front bags are constructed much like the rear bags with reinforced leather sides and heavy duty nylon tops. The inside corners feature sewn-in nylon inserts to prevent the material from rolling under the stock. All Edgewood Front Bags are available for hunter stocks widths (2 1/4") or Benchrest stock widths (3"). Each of the two widths are offered in four different styles: Standard Bag, features 1/2" leather flaps extending along the bottom edges to be pinned under your rest top retaining bars. Or the flaps may be punched, notched, or cut away all together to custom fit your rest. Standard Bag w/reinforced top, has an extra thick top to hold desired forend shape. Farley Bag, which is narrower than the Standard Bag from front to back to specifically fit the Farley Co-Axial and Co-Axial II rests only. Farley Bag w/reinforced top, has an extra thick top to hold desired forend shape. These bags fit old style pre-2009 Farley tops only. New style bags also available.



Attributes

- Name: [EDGEWOOD SHOOTING BAGS STANDARD FRONT REST 2-1/4" HUNTER W/REINFORCED TOP SLICK](#)
- Manufacturer: [EDGEWOOD SHOOTING BAGS](#)
- Product no.: 100045622
- Mfr. No.: COMMON 2 1/4 IN
- Colour: Black/ Tan
- Material: 3M Slick,Leather
- Style: Front Bag,Rest Top
- Delivery weight: 0.091kg
- Shipping height: 102mm
- Shipping width: 102mm
- Shipping length: 178mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for Edgewood Front Benchrest Bags
- About Us

Safety Instruction Guide for Edgewood Front Benchrest Bags

Introduction

Thank you for choosing the Edgewood Front Benchrest Bags. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of the product. Please read this document carefully before use to understand the safety measures and instructions.

General Safety Guidelines

- **Product Safety:** Ensure safe use of the Edgewood Front Benchrest Bags by following all instructions provided. This product is designed for use with firearms and requires careful handling.
- **Enhanced Recalls:** In the event of a product recall, you will be notified through standardized recall notices. Free remedies will be provided for any dangerous products.
- **Online Shopping:** If purchased online, know that you have the same safety protections as if you bought it in a physical store. Ensure that the online platform meets safety requirements.
- **Special Consumer Focus:** Extra care should be taken when children are nearby. This product is not intended for use by children.
- **EU Contact Point:** For safety inquiries, please refer to the designated EU contact point associated with this product.
- **Rapid Alerts:** Stay informed about unsafe products through the EU's Safety Gate platform, which provides faster updates.

Specific Safety Precautions for Use

- **Avoid Overloading:** Do not exceed the recommended weight limit when using the bag. Overloading can cause instability or damage.
- **Inspect Before Use:** Always inspect the bag for any signs of wear or damage before each use. Do not use if any parts are compromised.
- **Stable Surface Required:** Ensure that the bag is placed on a stable and level surface to prevent tipping or sliding during use.
- **Use Proper Sand:** Fill the bag with Extra Heavy Bag Sand only. Using other materials can compromise the bag's performance and safety.
- **Keep Away from Heat:** Avoid exposing the bag to high temperatures or open flames, as this can damage the materials.
- **Secure Firearms:** Always ensure that firearms are securely placed in the bag to prevent accidental movement or discharge.
- **Supervision of Vulnerable Groups:** If children or inexperienced users are present, ensure they are supervised at all times during use.

Instructions for Installation and Usage

1. Filling the Bag:

- Use Extra Heavy Bag Sand to fill the bag.
- Use a small funnel to assist in filling.
- Do not overfill; leave some space for the sand to shift.

2. Setting Up the Bag:

- Place the filled bag on a stable surface.
- Adjust the position of the bag to ensure it is level and secure.

3. **Using the Bag:**

- Position your firearm securely on the bag.
- Adjust the bag as necessary to achieve the desired height and angle for shooting.

4. **PostUse Care:**

- After use, remove any sand if necessary and store the bag in a cool, dry place.
- Inspect the bag for any damage before storing.

Disposal Instructions

- **Disposal of the Bag:** When the bag is no longer needed, dispose of it in accordance with local regulations for textile waste. Check for recycling options in your area.
- **Disposal of Sand:** Dispose of any sand according to local waste management guidelines. Do not dispose of in water sources or natural habitats.

Contact Information for Further Support

For any questions or concerns regarding the Edgewood Front Benchrest Bags, please refer to the designated EU contact point associated with this product. Ensure you have the product details available for reference.

By following these safety instructions, you can ensure a safe and enjoyable experience with your Edgewood Front Benchrest Bags. Thank you for your attention to these important guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk