

COMFORT STRETCH RIFLE SLING - BUTLER CREEK COMFORT STRETCH RIFLE SLING MOSSY OAK BREAK-UP COUNTRY

[Shooting Accessories](#) > [Slings & Sling Swivels](#) > [Slings](#)

Its stretchable construction and soft padding soak up the bounce you get with traditional slings - reducing felt weight up to 50% - so even the roughest hikes are smooth on your shoulder. Soft, flexible closed cell neoprene with Comfort Stretch backing Dramatically reduces felt weight Non-slip Grippers keep it firmly in place Available in popular camo patterns



Attributes

- Name: [BUTLER CREEK COMFORT STRETCH RIFLE SLING MOSSY OAK BREAK-UP COUNTRY](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 100046035
- Mfr. No.: 181017
- Colour: Mossy Oak Breakup Country
- Material: Neoprene,Nylon
- Style: 2-point Sling
- Width: 2-1/4"
- Delivery weight: 0.179kg
- Shipping height: 51mm
- Shipping width: 114mm
- Shipping length: 432mm
- UPC: 051525181019

Table of Contents

- [Startpage](#)
- [Safety Instruction Guide for COMFORT STRETCH RIFLE SLING](#)
- [About Us](#)

Safety Instruction Guide for COMFORT STRETCH RIFLE SLING

Introduction

Thank you for choosing the COMFORT STRETCH RIFLE SLING by Butler Creek. This guide provides important safety information and instructions to ensure the safe and effective use of your rifle sling. Please read this guide carefully before using the product.

General Safety Guidelines

- Ensure the rifle sling is suitable for your specific firearm and intended use.
- Inspect the sling for any signs of damage or wear before each use.
- Avoid using the sling in extreme weather conditions that may affect its performance.
- Keep the sling away from sharp objects that may cause cuts or damage.
- Always handle firearms responsibly and in accordance with local laws and regulations.

Specific Safety Precautions for Use

- Use the sling only for its intended purpose as a firearm accessory.
- Do not exceed the weight limit of the sling; refer to the product specifications for details.
- Ensure that the sling is securely attached to both the firearm and your body.
- When not in use, store the sling in a safe place away from children and pets.
- Be cautious of the nonslip grippers; ensure they are functioning properly to prevent accidental slips.

Instructions for Installation and Usage

1. Installation:

- Locate the attachment points on your firearm.
- Attach the sling to the front and rear sling swivels or mounting points securely.
- Ensure the sling is adjusted to the appropriate length for your comfort and use.

2. Usage:

- Place the sling over your shoulder, ensuring it is positioned comfortably.
- Adjust the sling to fit snugly against your body to minimize movement during use.
- When carrying your firearm, ensure the sling does not obstruct your movement or visibility.
- To transition from carrying to shooting position, practice adjusting the sling as needed for quick access.

Disposal Instructions

- Dispose of the sling in accordance with local regulations.
- If the sling is damaged beyond repair, consider recycling materials where applicable.
- Do not discard the sling in regular household waste if it can be recycled or reused.

Contact Information for Further Support

For any safety inquiries or concerns regarding your COMFORT STRETCH RIFLE SLING, please contact the manufacturer directly through their official communication channels. Always ensure you have the product details available when seeking assistance.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your COMFORT STRETCH RIFLE SLING. Always prioritize safety and responsible firearm handling. Thank you for your attention to these important guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk