

FLASH HIDER FOR RUGER™ 10/22™ - SAMSON MANUFACTURING CORP FLASH HIDER FOR RUGER 10/22 STAINLESS STEEL

[Rifle Parts](#) > [Muzzle Devices](#) > [Flash Hiders](#)

This flash hider slips on to the standard 10/22® rifle barrel is secured with a single set screw... no gunsmithing required.



Attributes

- Name: [SAMSON MANUFACTURING CORP FLASH HIDER FOR RUGER 10/22 STAINLESS STEEL](#)
- Manufacturer: [SAMSON MANUFACTURING CORP](#)
- Product no.: 100047444
- Mfr. No.: 04-06062-00
- Caliber: 22 Caliber (.223-.224)
- Finish: Stainless Steel
- Material: Stainless Steel
- Model: 10/22
- Weapon type: Ruger
- Delivery weight: 0.091kg
- Shipping height: 38mm
- Shipping width: 127mm
- Shipping length: 127mm
- UPC: 850006871780

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [FLASH HIDER FOR RUGER™ 10/22™ SAFETY INSTRUCTION GUIDE](#)
- [About Us](#)

FLASH HIDER FOR RUGER™ 10/22™ SAFETY INSTRUCTION GUIDE

Introduction

Thank you for choosing the FLASH HIDER FOR RUGER™ 10/22™ by SAMSON MANUFACTURING CORP. This product is designed to enhance your shooting experience while ensuring safety and compliance with applicable regulations. Please read this safety instruction guide carefully before using the product to ensure safe and effective use.

General Safety Guidelines

- Ensure that you are of legal age to purchase and use this product in your jurisdiction.
- Always treat firearms and their accessories as if they are loaded.
- Keep the flash hider out of reach of children and unauthorized users.
- Always wear appropriate eye and ear protection when using firearms.
- Regularly inspect the flash hider for any signs of wear or damage before use.
- Follow all local laws and regulations regarding firearm accessories.

Specific Safety Precautions for Use

- Do not attempt to modify the flash hider in any way.
- Ensure the rifle is unloaded before installing or removing the flash hider.
- Avoid using the flash hider in conditions where it may cause excessive heat buildup, such as rapid firing.
- Be aware that the flash hider may not eliminate all muzzle flash; it is designed to reduce it.
- Do not use the flash hider with ammunition that exceeds the specified caliber limits.

Instructions for Installation and Usage

1. Installation

- Ensure that the rifle is unloaded and pointed in a safe direction.
- Identify the standard 10/22® rifle barrel.
- Slide the flash hider onto the barrel until it is properly positioned.
- Secure the flash hider using the provided set screw. Tighten the screw firmly but do not overtighten to avoid damage.
- Doublecheck that the flash hider is securely attached before use.

2. Usage

- Always ensure the flash hider is properly installed before firing the rifle.
- Follow all standard firearm safety practices during usage.
- After use, allow the flash hider to cool down before handling, as it may become hot.

Disposal Instructions

- Dispose of the flash hider in accordance with local regulations regarding metal waste.
- Do not dispose of the flash hider in regular household waste.
- If the product is damaged or no longer usable, consider recycling the material if possible.

Contact Information for Further Support

For any questions or concerns regarding the FLASH HIDER FOR RUGER™ 10/22™, please refer to the manufacturer's official website or customer support channels. Always keep this safety instruction guide for future reference.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience while using the FLASH HIDER FOR RUGER™ 10/22™. Always prioritize safety and adhere to all relevant guidelines and regulations. Thank you for your attention to safety and your commitment to responsible firearm use.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk