

NONSTOP POLYMER ACTION COTTON T-SHIRT - MAGPUL NONSTOP POLYMER ACTION COTTON T-SHIRT SILVER 3X-LARGE

[Shooting Accessories](#) > [Apparel](#) > [Mens](#) > [Short Sleeves](#)

If Magpul made action figures 4.3 oz, 100% combed ring-spun cotton Crew neck with set-in sleeves Comfortable, tag-less interior neck label Shoulder to shoulder neck tape Double-needle stitching on hems and sleeves for durability
Printed in the USA Sizes: S, M, L, XL, 2XL, 3XL, 4XL



Attributes

- Name: [MAGPUL NONSTOP POLYMER ACTION COTTON T-SHIRT SILVER 3X-LARGE](#)
- Manufacturer: [MAGPUL](#)
- Product no.: 100048218
- Mfr. No.: MAG1221-040-3XL
- Colour: Silver
- Size: XXXL
- Delivery weight: 0.227kg
- Shipping height: 13mm
- Shipping width: 254mm
- Shipping length: 305mm
- UPC: 840815133667

Table of Contents

- Startpage
- NONSTOP POLYMER ACTION COTTON TSHIRT SAFETY INSTRUCTION GUIDE
- About Us

NONSTOP POLYMER ACTION COTTON TSHIRT SAFETY INSTRUCTION GUIDE

Introduction

Thank you for choosing the Magpul NONSTOP POLYMER ACTION COTTON TSHIRT. This guide provides essential safety information to ensure safe use and maintenance of your tshirt. By following these guidelines, you can help ensure your safety and the safety of others.

General Safety Guidelines

- Always inspect the tshirt before use. Check for any signs of damage or defects that may pose a risk.
- Keep the tshirt away from sharp objects that could cause tears or punctures.
- Follow washing and care instructions to maintain the integrity of the fabric and avoid hazards associated with wear and tear.
- Ensure that the tshirt is suitable for the intended use, especially if worn during physical activities.
- Be aware of any allergies or sensitivities to materials, such as cotton, that could cause skin reactions.

Specific Safety Precautions for Use

- Do not wear the tshirt near open flames or intense heat sources, as fabric can ignite.
- Avoid using the tshirt for activities that may cause excessive wear, such as heavy-duty labor, unless specifically designed for such use.
- If the tshirt becomes wet, allow it to dry completely before wearing to prevent discomfort or skin irritation.
- For children, ensure that the tshirt fits properly to avoid any risk of entanglement or choking hazards.

Instructions for Installation and Usage

• Wearing the TShirt:

- Slip the tshirt over your head, ensuring it fits comfortably around the neck and shoulders.
- Adjust the sleeves to ensure they are not too tight, allowing for ease of movement.

• Washing Instructions:

- Machine wash the tshirt in cold water with similar colors.
- Use mild detergent and avoid bleach to preserve color and fabric integrity.
- Tumble dry on low heat or hang to dry. Avoid high heat settings to prevent shrinkage.

• Storage Instructions:

- Store the tshirt in a cool, dry place away from direct sunlight to prevent fading.
- Fold or hang the tshirt to maintain its shape and prevent wrinkles.

Disposal Instructions

- When the tshirt is no longer usable, dispose of it responsibly. Consider donating it if it is in good condition.
- If the tshirt is damaged beyond repair, recycle the fabric if possible, or dispose of it in accordance with local waste management regulations.

Contact Information for Further Support

For any questions or concerns regarding the safety of this product, please refer to the official Magpul website or contact your local Magpul retailer for assistance.

Conclusion

By adhering to the guidelines provided in this safety instruction guide, you can ensure a safe and enjoyable experience with your Magpul NONSTOP POLYMER ACTION COTTON TSHIRT. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk