

REPLACEMENT DECAP PIN FOR LEE® UNIVERSAL DECAPPING DIE - LEE PRECISION LEE UNIVERSAL DECAP PIN

[Reloading](#) > [Case Cleaning](#) > [Decapping Dies & Accessories](#)

Lee replacement decapping pin for the Lee® Universal Decapping Die (#90292). Pin diameter .074" to .078".



Attributes

- Name: [LEE PRECISION LEE UNIVERSAL DECAP PIN](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 100053256
- Mfr. No.: 90783
- Delivery weight: 0.023kg
- Shipping height: 10mm
- Shipping width: 102mm
- Shipping length: 152mm
- UPC: 734307907839

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for Replacement Decap Pin for Lee® Universal Decapping Die
- About Us

Safety Instruction Guide for Replacement Decap Pin for Lee® Universal Decapping Die

Introduction

Thank you for choosing the Replacement Decap Pin for the Lee® Universal Decapping Die. This guide provides essential safety instructions and usage information to ensure your safety and the effective use of this product. Please read this guide carefully before use.

General Safety Guidelines

- Ensure safe use of this product by following all instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the decapping pin for wear and damage before each use.
- Do not use the decapping pin if it is damaged or shows signs of excessive wear.
- Use the product only for its intended purpose as described in this guide.

Specific Safety Precautions for Use

- Always wear safety glasses when using the decapping die to protect your eyes from debris.
- Avoid direct contact with the decapping pin while it is in use to prevent injury.
- Do not apply excessive force when using the decapping pin, as this may lead to breakage or injury.
- Ensure that the decapping die is securely attached to your reloading press before use.
- Store the decapping pin in a safe, dry place when not in use to prevent damage.

Instructions for Installation and Usage

1. Installation of the Decap Pin:

- Ensure the reloading press is turned off and unplugged.
- Remove the existing decap pin from the Lee® Universal Decapping Die by unscrewing it.
- Take the new replacement decap pin and align it with the die.
- Screw the decap pin into place until it is securely fastened.

2. Usage of the Decap Pin:

- Place a casing into the shell holder of the reloading press.
- Engage the press handle to lower the decapping pin into the casing.
- Apply steady, even pressure to decap the casing.
- Once decapping is complete, remove the casing and inspect the decap pin for any signs of wear or damage.

Disposal Instructions

- Dispose of the old decap pin and any damaged components in accordance with local regulations.
- Do not dispose of the product in household waste. Instead, check with local waste management services for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or further support regarding the Replacement Decap Pin for Lee® Universal Decapping Die, please refer to the manufacturer's contact details provided on the product packaging or visit the

manufacturer's website.

By adhering to these safety guidelines and instructions, you can ensure a safe and effective experience with the Replacement Decap Pin for the Lee® Universal Decapping Die. Always prioritize safety and report any unsafe conditions to the appropriate authorities. Thank you for your attention to these important safety measures.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk