

AUTO PRIME SHELLHOLDERS - LEE PRECISION LEE AUTO PRIME SHELLHOLDER #19

[Reloading](#) > [Shellholders & Shellplates](#)

Lee Universal Shell Holders function in the Lee handheld priming tools. Machined to close tolerances for maximum accuracy. Manufactured from hardened steel. View Lee Shellholder Chart



Attributes

- Name: [LEE PRECISION LEE AUTO PRIME SHELLHOLDER #19](#)
- Manufacturer: [LEE PRECISION](#)
- Product no.: 100053422
- Mfr. No.: 90023
- Cartridge: 357 SIG, 9 mm Luger, 40 S&W
- Style: Priming Tool
- Delivery weight: 0.045kg
- Shipping height: 8mm
- Shipping width: 95mm
- Shipping length: 84mm
- UPC: 734307900236

Item details

Made in USA

Table of Contents

- Startpage
- AUTO PRIME SHELLHOLDERS LEE PRECISION Safety Instruction Guide
- About Us

AUTO PRIME SHELLHOLDERS LEE PRECISION

Safety Instruction Guide

Introduction

Thank you for choosing the AUTO PRIME SHELLHOLDERS from LEE PRECISION. This product is designed to enhance your reloading experience by ensuring accurate and efficient priming of your cartridges. Please read this safety instruction guide carefully to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that you use the AUTO PRIME SHELLHOLDERS only for the specified cartridges: 9 mm Luger, 40 S&W, and 357 SIG.
- Always handle all reloading equipment, including shellholders, with care to avoid accidents.
- Keep the AUTO PRIME SHELLHOLDERS out of reach of children and vulnerable individuals.
- Regularly inspect the shellholders for signs of wear or damage before use.
- Follow all safety instructions provided by your reloading equipment manufacturer.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including safety glasses, when reloading ammunition.
- Do not exceed the recommended cartridge specifications when using the shellholders.
- Ensure that the priming tool is properly secured to prevent accidental disassembly during use.
- Avoid distractions while using the shellholders to maintain focus and prevent accidents.
- Store the shellholders in a cool, dry place away from direct sunlight and moisture.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press or priming tool is compatible with the LEE AUTO PRIME SHELLHOLDERS.
- Select the appropriate shellholder for your cartridge type (9 mm Luger, 40 S&W, or 357 SIG).
- Insert the shellholder into the priming tool until it clicks securely into place.

2. Usage:

- Prepare your cartridge cases by cleaning and inspecting them for defects.
- Place the cartridge case into the shellholder, ensuring it is seated properly.
- Follow the instructions of your priming tool to initiate the priming process.
- After priming, remove the cartridge case from the shellholder and inspect it for proper seating of the primer.

Disposal Instructions

- Dispose of any damaged or worn AUTO PRIME SHELLHOLDERS in accordance with local regulations for metal waste.
- Do not dispose of the shellholders in regular household waste. Instead, seek out recycling programs that accept metal components.

Contact Information for Further Support

For any inquiries related to safety or product support, please refer to the official LEE PRECISION website or contact your local retailer.

Conclusion

By following these safety instructions, you can ensure a safe and effective experience with the AUTO PRIME SHELLHOLDERS from LEE PRECISION. Always prioritize safety and compliance with all applicable regulations when handling reloading equipment. Thank you for your attention to these important guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk