

T3/T3X BOLT KNOBS - MOUNTAIN TACTICAL T3/T3X BOLT KNOBS - KNULED

[Rifle Parts](#) > [Bolt Parts](#) > [Charging Handle Parts](#) > [Charging Handles](#)

Replacement Bolt Knobs from Mountain Tactical. Available in multiple options like Knurled, Outdoorsman, and Outdoorsman XL.



Attributes

- Name: [MOUNTAIN TACTICAL T3/T3X BOLT KNOBS - KNULED](#)
- Manufacturer: [MOUNTAIN TACTICAL](#)
- Product no.: 100061476
- Mfr. No.: T3T3XBHK-K
- Finish: Black
- Model: T3,T3x
- Weapon type: Tikka
- Delivery weight: 0.025kg
- Shipping height: 165mm
- Shipping width: 76mm
- Shipping length: 165mm
- UPC: 811291030405

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- T3/T3X Bolt Knobs Safety Instructions
- About Us

T3/T3X Bolt Knobs Safety Instructions

Introduction

Thank you for choosing the T3/T3X Bolt Knobs from Mountain Tactical. These replacement bolt knobs are designed for the Tikka T3 and T3x models and are available in various styles, including Knurled, Outdoorsman, and Outdoorsman XL. This safety instruction guide is provided to ensure the safe and effective use of your product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as specified.
- Always read the instructions carefully before installation and use.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Do not use the bolt knobs if they show signs of damage or wear.
- Ensure that the bolt knobs are securely attached before using the firearm.
- Avoid using excessive force when installing or adjusting the bolt knobs.
- Be aware of your surroundings and ensure a safe environment when handling firearms.
- Always follow the manufacturer's guidelines for the safe operation of your firearm.

Instructions for Installation and Usage

1. Installation:

- Remove the existing bolt knob from your Tikka T3 or T3x rifle.
- Align the new bolt knob with the bolt shaft.
- Carefully screw the new bolt knob onto the bolt shaft until it is secure.
- Ensure that the bolt knob is properly tightened and does not wobble.

2. Usage:

- Operate the bolt knob gently to avoid any potential damage.
- Always check that the bolt is functioning correctly after installation.
- Use the bolt knob to chamber rounds and eject spent casings in a safe manner.
- Maintain awareness of your firearm's condition and functionality during use.

Disposal Instructions

- Dispose of any damaged or worn bolt knobs in accordance with local waste disposal regulations.
- Do not throw the product in general household waste; check for recycling options available in your area.

Contact Information for Further Support

For any questions or concerns regarding the T3/T3X Bolt Knobs, please reach out to the appropriate support channels for assistance.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk