

PADDED MAGIC CARPET SHOOTING MAT - EBERLESTOCK PADDED MAGIC CARPET SHOOTING MAT

[Shooting Accessories](#) > [Range Gear](#) > [Shooting Mats/Stools](#)

Prone-Position Shooting with Added Comfort

The Eberlestock Padded Magic Carpet Shooting Mat provides all of the same benefits as the company's original Magic Carpet mat but enhances the shooting experience with the addition of extra padding for added comfort. The Eberlestock Magic Carpet Shooting Mat offers extra coverage for shooters looking to keep their entire rifle over the mat, ensuring that dust isn't kicked up with each shot. The mat also provides enough length to allow shooters to stay dry and comfortable. Constructed using Nylon and PVC for waterproofing Available in coyote brown Features weighted end that allows for rapid deployment Once shooting is finished, the Eberlestock Magic Carpet Shooting Mat rolls up into a compact package for hiking into and out of the country.



The Eberlestock Padded Magic Carpet Shooting Mat provides all of the same benefits as the company's original Magic Carpet mat but enhances the shooting experience with the addition of extra padding for added comfort. The Eberlestock Magic Carpet Shooting Mat offers extra coverage for shooters looking to keep their entire rifle over the mat, ensuring that dust isn't kicked up with each shot. The mat also provides enough length to allow shooters to stay dry and comfortable. Constructed using Nylon and PVC for waterproofing Available in coyote brown Features weighted end that allows for rapid deployment Once shooting is finished, the Eberlestock Magic Carpet Shooting Mat rolls up into a compact package for hiking into and out of the country.

Attributes

- Name: [EBERLESTOCK PADDED MAGIC CARPET SHOOTING MAT](#)
- Manufacturer: [EBERLESTOCK](#)
- Product no.: 100080017
- Mfr. No.: A2SM
- Material: Nylon,PVC
- Style: Shooting Mat
- Delivery weight: 1.814kg
- Shipping height: 102mm
- Shipping width: 279mm
- Shipping length: 445mm
- UPC: 812028011315

Table of Contents

- Startpage
- Eberlestock Padded Magic Carpet Shooting Mat Safety Instructions
- About Us

Eberlestock Padded Magic Carpet Shooting Mat Safety Instructions

Introduction

Thank you for choosing the Eberlestock Padded Magic Carpet Shooting Mat. This product is designed to enhance your shooting experience while ensuring safety and comfort. Please read this safety instruction guide carefully to understand how to use the mat safely and effectively.

General Safety Guidelines

- Ensure that the shooting mat is used in a safe environment, away from bystanders and potential hazards.
- Always inspect the mat for any signs of damage or wear before use. Do not use if damaged.
- Keep the mat clean and dry to maintain its performance and safety features.
- Be aware of your surroundings when using the mat, including potential obstacles and hazards.
- Follow all local laws and regulations regarding shooting activities.

Specific Safety Precautions for Use

- Use the mat only for its intended purpose: as a shooting mat.
- Ensure that the mat is fully unrolled and laid flat on the ground before use.
- Avoid shooting over or near the edges of the mat to prevent accidental injury.
- Be cautious of the weight of your rifle and ensure it is securely placed on the mat.
- Always wear appropriate safety gear, such as eye and ear protection, when using firearms.
- Keep children and pets away from the shooting area at all times.

Instructions for Installation and Usage

1. Preparation

- Choose a flat and stable surface for setting up the mat.
- Ensure the area is clear of debris, rocks, or any objects that could cause injury.

2. Unrolling the Mat

- Carefully unroll the Eberlestock Padded Magic Carpet Shooting Mat.
- Ensure that it is fully extended and laid flat on the ground.

3. Positioning

- Position the mat so that it provides adequate coverage for your shooting stance.
- Ensure that your rifle is fully supported by the mat to avoid dust and debris being kicked up.

4. Shooting

- Once you are in position, doublecheck that the area is safe and clear of bystanders.
- Use the mat to support your rifle and maintain a stable shooting position.
- After shooting, ensure that the area remains safe before packing up.

5. Rolling Up the Mat

- After use, carefully roll up the mat starting from one end.
- Ensure that it is tightly rolled to minimize space for transportation.

Disposal Instructions

- Dispose of the Eberlestock Padded Magic Carpet Shooting Mat in accordance with local regulations.
- If the mat is damaged beyond repair, consider recycling the materials where possible.
- Do not dispose of the mat in regular household waste if it contains materials that can be recycled.

Contact Information for Further Support

For any safety inquiries or further assistance regarding the Eberlestock Padded Magic Carpet Shooting Mat, please refer to the contact point provided with your product purchase. Ensure that you have the product details on hand for efficient support.

Thank you for your attention to these safety instructions. Enjoy your shooting experience with the Eberlestock Padded Magic Carpet Shooting Mat while prioritizing safety and compliance with regulations.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk