

GUIDE ROD ASSEMBLY FOR GLOCK® - LONE WOLF DIST. M20, M21, M40 & M41 LONE WOLF GENERATION 4 STAINLESS STEEL

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Guide Rods](#)

Solid stainless steel guide rod. Precision CNC machined to accept a removable Allen head tip, for easy spring changes. Springs are made from 17-7 stainless steel and are calibrated to factory weights.



Attributes

- Name: [LONE WOLF DIST. M20, M21, M40 & M41 LONE WOLF GENERATION 4 STAINLESS STEEL](#)
- Manufacturer: [LONE WOLF DIST.](#)
- Product no.: 100803030
- Mfr. No.: LWD-GRA21G4-SAT
- Model: 21,41,20,40
- Weapon type: Glock
- Delivery weight: 0.408kg
- Shipping height: 178mm
- Shipping width: 13mm
- Shipping length: 76mm
- UPC: 639737068443

Item details

Made in USA

US export classification: 0A501.x

Table of Contents

- Startpage
- Safety Instruction Guide for GUIDE ROD ASSEMBLY FOR GLOCK® LONE WOLF DIST. M20, M21, M40 & M41 LONE WOLF GENERATION 4 STAINLESS STEEL
- About Us

Safety Instruction Guide for GUIDE ROD ASSEMBLY FOR GLOCK® LONE WOLF DIST. M20, M21, M40 & M41 LONE WOLF GENERATION 4 STAINLESS STEEL

Introduction

Thank you for purchasing the Guide Rod Assembly for Glock® Lone Wolf Dist. M20, M21, M40 & M41 Lone Wolf Generation 4 Stainless Steel. This guide provides important safety information, installation instructions, and usage guidelines to ensure your safety and the proper functioning of the product.

General Safety Guidelines

- Always ensure that the firearm is unloaded before attempting to install or remove the guide rod assembly.
- Keep the product out of reach of children and unauthorized users.
- Inspect the guide rod and springs for wear or damage before each use.
- Do not use the guide rod assembly if it shows signs of damage or if you are unsure of its condition.
- Follow all local laws and regulations regarding the use and modification of firearms.
- Store the guide rod assembly in a safe and secure location when not in use.

Specific Safety Precautions for Use

- Ensure that you are using the correct model of the guide rod assembly for your Glock® firearm (Models: 20, 21, 40, 41).
- Use only the recommended springs made from 177 stainless steel for optimal performance.
- When changing springs, always use caution and follow the instructions carefully to avoid injury.
- Wear safety glasses when handling springs to protect your eyes from potential injury.
- Never point the firearm at yourself or others while handling or installing the guide rod assembly.

Instructions for Installation and Usage

1. Preparation

- Ensure that the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools, including an Allen wrench for the removable tip.

2. Removing the Old Guide Rod

- Remove the slide from the firearm according to the manufacturer's instructions.
- Carefully remove the old guide rod assembly from the slide.

3. Installing the New Guide Rod

- Take the new guide rod assembly and insert it into the slide.
- Ensure that it is seated properly and securely.

4. Changing Springs

- To change the spring, use the Allen wrench to remove the Allen head tip from the guide rod.
- Replace the old spring with a new one, ensuring it is calibrated to factory weights.

- Reattach the Allen head tip securely.

5. Reassembling the Firearm

- Once the new guide rod assembly is installed, reattach the slide to the firearm.
- Perform a function check to ensure everything is working correctly.

Disposal Instructions

- Dispose of the old guide rod assembly and springs in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Check with local authorities for proper disposal methods for stainless steel and other materials.

Contact Information for Further Support

For any safety inquiries or concerns regarding the product, please refer to the manufacturer's website or contact the authorized dealer from whom you purchased the guide rod assembly.

By following these guidelines, you can ensure the safe and effective use of the Guide Rod Assembly for Glock® Lone Wolf Dist. M20, M21, M40 & M41 Lone Wolf Generation 4 Stainless Steel. Thank you for prioritizing safety in your firearm practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk