

FLIP OPEN EYEPIECE LENS COVERS - BUTLER CREEK EYEPIECE LENS COVER #16 1.660" (42.2MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

Keeps Harmful Debris From Scratching Or Abusing Lenses

Weatherproof, dust-proof, moisture-proof scope covers protect your scope's lenses from being damaged during tactical and hunting situations. Cover flips open easily with finger pressure to spring up, and out of the way. Eye and Objective covers sold separately. To determine the correct scope cover, measure the diameter of your scope eyepiece or objective and use the chart.



Attributes

- Name: [BUTLER CREEK EYEPIECE LENS COVER #16 1.660" \(42.2MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 120000013
- Mfr. No.: 20160
- Colour: Black
- End Fit: Ocular
- Model Number: 1.660" (42.2MM)
- Size: 1.66
- Delivery weight: 0.045kg
- Shipping height: 41mm
- Shipping width: 69mm
- Shipping length: 122mm
- UPC: 051525201601

Table of Contents

- Startpage
- Safety Instruction Guide for FLIP OPEN EYEPIECE LENS COVERS
- About Us

Safety Instruction Guide for FLIP OPEN EYEPIECE LENS COVERS

Introduction

Thank you for choosing the FLIP OPEN EYEPIECE LENS COVERS by BUTLER CREEK. These lens covers are designed to protect your scope's lenses from damage during tactical and hunting situations. This guide provides essential safety instructions to ensure the safe use and maintenance of your product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the lens covers are installed correctly to avoid any accidental damage to your scope.
- Regularly inspect the lens covers for wear and tear. Replace them if they show signs of damage.
- Keep the lens covers clean and free from debris to maintain optimal performance.
- Store the lens covers in a cool, dry place when not in use.
- Avoid exposing the lens covers to extreme temperatures or harsh chemicals.

Specific Safety Precautions for Use

- Do not force the covers open or closed. Use gentle finger pressure to flip them open.
- Keep the lens covers out of reach of children to prevent accidental injury or choking hazards.
- Do not use the lens covers if they are damaged or if the spring mechanism is not functioning correctly.
- Ensure that the lens covers are compatible with your scope's eyepiece and objective diameters before use.

Instructions for Installation and Usage

1. Measuring Your Scope:

- Measure the diameter of your scope's eyepiece or objective to determine the correct size lens cover.
- Refer to the provided size chart to select the appropriate cover.

2. Installing the Lens Covers:

- Align the lens cover with the eyepiece or objective.
- Gently press the cover onto the lens until it fits securely.

3. Using the Lens Covers:

- To open the cover, apply gentle finger pressure to flip it open.
- Ensure the cover is fully opened and out of the way before using the scope.

4. Removing the Lens Covers:

- To remove the cover, gently pull it away from the lens.
- Store the cover in a safe place when not in use.

Disposal Instructions

- Dispose of the lens covers responsibly. Check local regulations for proper disposal methods.
- Do not dispose of lens covers in regular household waste if they are classified as hazardous.

Contact Information for Further Support

For safety inquiries or support related to the FLIP OPEN EYEPIECE LENS COVERS, please refer to the manufacturer's contact information provided in the product packaging or on the official website.

Conclusion

By following these safety instructions, you can ensure the safe and effective use of your FLIP OPEN EYEPIECE LENS COVERS. Thank you for prioritizing safety and for choosing a quality product from BUTLER CREEK. Enjoy your outdoor activities with confidence!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk