

FLIP OPEN EYEPIECE LENS COVERS - BUTLER CREEK EYEPIECE LENS COVER #14 1.605" (40.8MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

Keeps Harmful Debris From Scratching Or Abusing Lenses

Weatherproof, dust-proof, moisture-proof scope covers protect your scope's lenses from being damaged during tactical and hunting situations. Cover flips open easily with finger pressure to spring up, and out of the way. Eye and Objective covers sold separately. To determine the correct scope cover, measure the diameter of your scope eyepiece or objective and use the chart.



Attributes

- Name: [BUTLER CREEK EYEPIECE LENS COVER #14 1.605" \(40.8MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 120000015
- Mfr. No.: MO20140
- Colour: Black
- End Fit: Ocular
- Model Number: 1.605" (40.8MM)
- Size: 1.605
- Delivery weight: 0.032kg
- Shipping height: 36mm
- Shipping width: 69mm
- Shipping length: 127mm
- UPC: 051525201403

Table of Contents

- Startpage
- FLIP OPEN EYEPIECE LENS COVERS SAFETY INSTRUCTIONS
- About Us

FLIP OPEN EYEPIECE LENS COVERS SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the Butler Creek Eyepiece Lens Cover #14. This product is designed to protect your scope's lenses from weather, dust, and moisture during tactical and hunting situations. To ensure safe and effective use, please read and follow these safety instructions carefully.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always inspect the lens cover for any damage before use. Do not use if damaged.
- Keep the lens cover out of reach of children to avoid choking hazards.
- Avoid exposing the product to extreme temperatures or direct sunlight for extended periods.
- Regularly check for wear and tear and replace the product if necessary.
- Report any unsafe conditions or accidents to relevant authorities.

Specific Safety Precautions for Use

- Do not force the cover open or closed. Use gentle finger pressure to operate the flip mechanism.
- Ensure that the cover is securely attached to the eyepiece before use to prevent accidental detachment.
- When using the cover, be mindful of your surroundings to avoid tripping or falling.
- If the cover becomes wet, allow it to dry completely before storing it to prevent mold or mildew.
- Do not use the lens cover in conjunction with incompatible products, as this may lead to damage.

Instructions for Installation and Usage

1. Measuring Your Scope:

- Measure the diameter of your scope eyepiece or objective.
- Refer to the provided chart to determine the correct size for your lens cover.

2. Installation:

- Align the lens cover with the eyepiece.
- Press firmly but gently until the cover is securely in place.
- Ensure the cover is flush against the eyepiece to prevent any gaps.

3. Usage:

- To open the cover, apply light finger pressure to the designated area.
- The cover will spring open and stay out of the way during use.
- When finished, gently press the cover back into the closed position.

Disposal Instructions

- Dispose of the lens cover in accordance with local waste disposal regulations.
- If the product is damaged or no longer usable, ensure it is disposed of in a way that minimizes environmental impact.
- Do not incinerate or expose the product to extreme heat during disposal.

Contact Information for Further Support

For safety inquiries or further assistance, please contact the manufacturer or refer to the product packaging for additional information.

Note:

This safety instruction guide is designed to comply with the EU General Product Safety Regulation (GPSR). Please ensure that you follow these guidelines to ensure safe usage of the Butler Creek Eyepiece Lens Cover #14. Thank you for prioritizing safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk