

FLIP-OPEN OBJECTIVE LENS COVERS - BUTLER CREEK OBJECTIVE LENS COVER #30 1.960" (49.8MM)

[Optics & Mounting](#) > [Optic Accessories](#) > [Scope Lens Covers](#)

Keeps Harmful Debris From Scratching Or Abusing Lenses

Weatherproof, dust-proof, moisture-proof scope covers protect your scope's lenses from being damaged during tactical and hunting situations. Cover flips open easily with finger pressure to spring up, and out of the way. Eye and Objective covers sold separately. To determine the correct scope cover, measure the diameter of your scope eyepiece or objective and use the chart.



Attributes

- Name: [BUTLER CREEK OBJECTIVE LENS COVER #30 1.960" \(49.8MM\)](#)
- Manufacturer: [BUTLER CREEK](#)
- Product no.: 120000022
- Mfr. No.: 30300
- Colour: Black
- End Fit: Objective
- Model Number: 1.960" (49.8MM)
- Size: 1.96
- Delivery weight: 0.027kg
- Shipping height: 41mm
- Shipping width: 69mm
- Shipping length: 122mm
- UPC: 051525303008

Table of Contents

- [Startpage](#)
- [FLIPOPEN OBJECTIVE LENS COVERS SAFETY INSTRUCTIONS](#)
- [About Us](#)

FLIPOPEN OBJECTIVE LENS COVERS SAFETY INSTRUCTIONS

Introduction

Thank you for choosing the FLIPOPEN OBJECTIVE LENS COVERS by Butler Creek. These covers are designed to protect your scope's lenses from weather, dust, and moisture during tactical and hunting situations. This safety instruction guide outlines essential safety guidelines and instructions for the proper use and disposal of the product to ensure your safety and satisfaction.

General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Always inspect the lens covers before use for any signs of damage or wear.
- Keep the lens covers out of reach of children to prevent accidental injury or misuse.
- Do not use the product if it is damaged or malfunctioning.
- Follow all local laws and regulations regarding the use of optical equipment.

Specific Safety Precautions for Use

- **Avoid Extreme Conditions:** Do not expose the lens covers to extreme temperatures or harsh chemicals, as this may compromise their integrity.
- **Proper Handling:** Handle the covers with care to avoid dropping or impacting them, which may cause damage.
- **Secure Fit:** Ensure that the covers fit securely on your scope to prevent them from becoming loose during use.
- **Check Compatibility:** Before purchasing, measure the diameter of your scope eyepiece or objective to ensure the correct fit. Refer to the provided size chart for guidance.

Instructions for Installation and Usage

Installation

1. Measure Your Scope:

- Use a caliper or measuring tape to measure the diameter of your scope's eyepiece or objective.
- Refer to the size chart to select the appropriate lens cover size.

2. Attach the Lens Cover:

- Align the cover with the scope's eyepiece or objective.
- Press the cover firmly into place until it fits securely.

Usage

• Opening the Cover:

- To open the cover, apply gentle finger pressure to flip it open. The cover will spring up and out of the way for easy access to the lens.

• Closing the Cover:

- When not in use, close the cover securely to protect the lens from dust and moisture.

Disposal Instructions

- Dispose of the lens covers in accordance with local regulations regarding plastic waste.
- Do not incinerate or expose the covers to open flames.
- If the product is no longer usable, consider recycling options if available in your area.

Contact Information for Further Support

For any inquiries regarding safety or product information, please refer to the contact details provided on the product packaging or the manufacturer's website.

Thank you for your attention to these safety instructions. Enjoy your FLIPOPEN OBJECTIVE LENS COVERS and ensure safe and effective use during your tactical and hunting experiences.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk